

PARSUN OUTBOARD MOTOR SERVICE MANUAL

F60/50

Suzhou Parsun Power Machine Co., Ltd.

Introduction

This Manual is a repair instruction for F50/60 and is provided by Parsun to the dealers when maintaining or repairing Parsun outboard motors. Please read this Manual carefully before maintaining and servicing the outboard motor. Please use the repair procedures and tools recommended in this

Manual when repairing and maintaining the outboard motor. If other maintenance procedures and tools are selected, please follow the instructions of experienced maintenance personnel to avoid injury to personnel and outboard motor.

The information, drawings and technical parameters used in this Manual are subject to the prototype at the time of publication, so there can be slight differences between the actual motor you purchased and that described in the Manual. If necessary, the Company will distribute the revised part to the dealers.

When the following characters appear in the Manual, please read the Manual carefully and follow the relevant instructions and descriptions correctly and carefully.

 **Warning:**

Failure to obey the warning may cause injuries to maintenance personnel and bystanders, and in serious cases, this may lead to death.

Attention:

Preventive measures must be taken to prevent outboard motor from being damaged.

Note:

Provide you with key information to make your operation steps simpler and clearer.

The last part of this Manual provides the common faults and troubleshooting methods of outboard motors, so please read them carefully, and it can help you quickly judge the status of the outboard motor and improve your working efficiency when overhauling the motor.

It is forbidden to copy and distribute this Manual without written authorization.

Suzhou Parsun Power Machine Co., Ltd.

After-sales service: 400-882-6659

0512-66212797

Contents

| | |
|---|----|
| Overview | 1 |
| Identification Marks..... | 1 |
| Propeller Selection..... | 1 |
| Protective Measure at Work..... | 1 |
| Disassembling and Assembling | 2 |
| Disposable Parts | 2 |
| Inspection before Delivery | 3 |
| Special Tools and Testing Equipment..... | 4 |
| Decomposition Schematic Diagram and Symbolic Description..... | 5 |
| Specifications..... | 7 |
| Parameters of Outboard Motor | 7 |
| Repair Information..... | 8 |
| Engine..... | 8 |
| Measurement conditions:..... | 9 |
| Lower casing Installation..... | 9 |
| Electrical System | 9 |
| Ignition and Ignition Control System | 9 |
| Locking Torque..... | 9 |
| Specified Torque | 9 |
| General Torque | 10 |
| Dimensions | 11 |
| Outline Dimension(D/T model)..... | 11 |
| Mounting dimensions of clamp bracket..... | 13 |
| Basic Maintenance..... | 14 |
| Maintenance Interval Chart | 14 |
| Fuel System | 14 |
| Engine..... | 15 |
| Engine Oil Level..... | 15 |
| Replace Engine Oil..... | 15 |
| Valve Clearance | 16 |
| Spark Plug..... | 16 |
| Control System | 17 |
| Throttle Cable..... | 17 |
| Shift Operation..... | 17 |
| Lower Casing Unit..... | 18 |
| Gear Oil | 18 |
| Change gear oil | 18 |
| Air tightness Inspection of Lower casing Unit | 18 |
| General maintenance | 18 |
| Anode..... | 18 |
| Lubrication Point | 19 |
| Cooling Water Channel..... | 19 |
| Thermostat | 19 |
| Propeller..... | 20 |
| Electrical System | 20 |
| Attention: | 20 |
| Decomposition Schematic Diagram | 21 |
| Wiring Diagram | 27 |


| | |
|--|----|
| Spark Plug Ignition | 29 |
| Spark Plug Cap | 29 |
| Flywheel Maintenance..... | 29 |
| Check the Ignition Coil..... | 29 |
| Check the trigger coil..... | 29 |
| Check the Engine Start Switch | 30 |
| Check the Engine Start Switch | 30 |
| Check the Starting Relay | 30 |
| Check the Magneto Coil | 30 |
| Check the Rectifier Regulator..... | 30 |
| How to Use the Diagnostic Scan Tool | 31 |
| Fault Code Table..... | 31 |
| Fuel System | 33 |
| Attention: | 33 |
| Decomposition Schematic Diagram | 34 |
| Relieve the Fuel Pressure in the Fuel Lines..... | 39 |
| Remove and Check the Fuel Joint | 39 |
| Remove and Check the Fuel Pump..... | 40 |
| Check the Fuel Filter | 41 |
| Remove and Check the Electric Fuel Pump | 41 |
| Disassembly of electric fuel pump..... | 41 |
| Check the Fuel Pipe and Fuel Filter..... | 42 |
| Check the Fuel Common Rail..... | 42 |
| Check the fuel common rail for leaks or cracks and damage, and replace it if necessary. | 42 |
| Engine..... | 42 |
| Attention: | 42 |
| Decomposition Schematic Diagram | 43 |
| Special Tools..... | 55 |
| Check the Compression Pressure..... | 55 |
| Check the Oil Pressure..... | 55 |
| Disassemble the Engine | 56 |
| Pulley and Timing Belt | 56 |
| Disassembling and Check..... | 57 |
| Cylinder Head..... | 57 |
| Crankcase..... | 61 |
| Reinstall..... | 65 |
| Assemble Piston Connecting Rod..... | 65 |
| Install the piston, connecting rod, piston pin and piston pin clip clutch | 65 |
| Install Piston Ring..... | 65 |
| Install Piston | 65 |
| Install Crankshaft..... | 65 |
| Assemble the Engine | 65 |
| Upper Casing | 67 |
| Top Cowling | 67 |
| Decomposition Schematic Diagram | 67 |
| Disassembling and Check..... | 68 |
| Bottom Cowling | 69 |
| Decomposition Schematic Diagram | 69 |
| Disassembling and Check..... | 73 |
| Steering Handle | 74 |

| | |
|--|-----|
| Decomposition Schematic Diagram | 74 |
| Disassembling and Check | 76 |
| Upper casing unit and Brackets | 77 |
| Decomposition Schematic Diagram | 77 |
| Disassembling and Check of Bracket | 83 |
| Disassembling and Check of Water Unit | 83 |
| Manual Tilting Device | 85 |
| Disassembly Schematic Diagram | 85 |
| Disassembling | 86 |
| Hydraulic Tilting Device | 87 |
| Disassembly Schematic Diagram | 87 |
| Disassembling | 88 |
| Oil Level Check | 88 |
| Discharge Air from Oil Circuit of the Hydraulic Tilting Device | 88 |
| Lower casing Part | 90 |
| Decomposition Schematic Diagram(D/T model) | 90 |
| Decomposition Schematic Diagram (CD/CT model) | 97 |
| Disassembling and Check | 99 |
| Propeller Shaft and Clutch Block | 100 |
| Install the Claw Clutch | 100 |
| Lower casing Unit Casing Cover | 101 |
| Install the Casing Cover Oil Seal and Bearing | 101 |
| Drive Shaft | 101 |
| Shift Cam | 101 |
| Gear | 101 |
| Forward Gear Bearing | 102 |
| Check the Lower casing Unit Casing | 102 |
| Check the Water Pipe | 102 |
| Assemble the Lower casing Device Casing | 102 |
| Install the Lower casing Unit | 103 |
| Selection of Shims | 104 |
| Deviation Value Mark | 104 |
| Pinion Shim | 105 |
| Shims for Forward Gear | 105 |
| Shims for Reverse Gear | 105 |
| Common Faults and Solutions | 106 |

Overview

Identification Marks


The serial number of the outboard motor is printed on a label, which is attached to the port side of the clamp bracket or the upper part of the rotary bracket. The serial number is shown in the whitespace of the label to help you order spare parts from the dealer or for reference when the engine is stolen.



1. SN of the outboard motor



The SN indicates the following:



Propeller Selection

The performance of the outboard motor is seriously affected by the selection of propellers. Improper propeller may have adverse effects on the engine. When running with heavy load, the engine will run at low speed for a long time.

At this time, the propeller with smaller pitch should be selected, otherwise the pitch should be selected.

Larger propeller to maintain normal operation of the engine.

When the engine is running at full throttle, refer to the speed and fuel performance of the engine for the most suitable propeller. In this way the propeller can provide the highest performance.

| Model | Propeller Dimension | Material |
|--|-----------------------------------|-----------------|
| C/D Model Gear ratio: 1.85:1 Gear box capacity:430cc | 3-11 $\frac{3}{8}$ " \times 12" | Aluminium alloy |
| | 3-11 $\frac{1}{8}$ " \times 13" | Aluminium alloy |
| CD/CT Model Gear ratio: 2.0:1 Gear box capacity:610cc | 3-13 $\frac{1}{4}$ " \times 17" | Aluminium alloy |
| | 3-13 $\frac{5}{8}$ " \times 13" | Aluminium alloy |

Protective Measure at Work

In order to prevent hazards or accidents during maintenance and improve work quality, please observe the following safety regulations.

1. Fire control

Gasoline and various lubricating oils and greases are highly combustible, so please keep away from heat sources, sparks and open flames when working.

2. Ventilation

Gasoline steam and engine exhaust gas are highly toxic. Massive inhalation of them can

cause shock and even death. Maintain good ventilation conditions when debugging the engine indoors.

3. Self-protection

Wear protective glasses when drilling, grinding or using air compressors. Wear protective gloves and safety shoes when necessary.

4. Use of lubricants and sealants

When maintaining and repairing outboard motors, only products provided or recommended by Parsun can be used.

Under normal circumstances, the lubricants mentioned in this Manual will not damage your skin. However, please take protective measures before use to reduce risks.

- ① Apply protective cream to both hands before overhauling outboard motors;
- ② If clothes are contaminated by lubricant, replace and clean them as soon as possible.
- ③ Avoid contact with skin;
- ④ Please wash your hands and skin carefully with soap and hot water after touching lubricant.
- ⑤ Use a clean, non-fuzzing rag to wipe off the spilled grease.

5. Developing good working habits

① Tighten nuts, bolts and screws according to the specified torque from the center outward and from large ones to small ones.

② Use recommended special tools to avoid damage to parts. Use the right tools in the right way.

Disassembling and Assembling

When disassembling and assembling an outboard motor, please observe the following principles:

1. Use special tools when disassembling and assembling parts;
2. Remove dust and dirt before disassembling parts;
3. Apply engine oil to the contact surface of moving parts before assembly;
4. When installing the bearing, place the manufacturer's mark in the specified direction and lubricate it fully.
5. Before installation, coat a thin layer of waterproof lubricating oil on the protruding part and periphery of the oil seal;
6. After the assembling is completed, check whether the moving parts are working properly.

Disposable Parts

Parts such as gaskets, oil seals, O-rings, cotter pins and spring rings are disposable parts and must be replaced when reinstalling the outboard motor.

Inspection before Delivery

In order to ensure the normal use of the products by customers, please carry out the following inspections before delivery.

1. Check the fuel system.

Check that the fuel hose is securely connected and that the fuel tank is full of fuel.



Attention:

This is a four-stroke engine and premixed fuel cannot be used.

2. Check oil level.

① Check engine oil level.

Pull out the oil dipstick and observe the oil level through the oil dipstick.




1. Oil dipstick 2. High position mark 3. Low position mark

Ensure that the oil level is between the high position mark and the low position mark; Drain the oil when the oil level is higher than the high position mark, and add oil when it is lower than the low position mark.

② Check gear oil level

Unscrew the oil level hole plug and observe whether there is oil overflow from the oil level plug hole.

If yes, install the oil level hole plug and tighten it according to the specified torque. If not, fill in oil.



1. Oil level hole plug

3. Check the steering system.

Check whether the steering is smooth;

4. Check shift and throttle operation.

Check whether the gear shift operation is smooth; Check whether the throttle grip operates smoothly from the fully closed position to the fully open position.

5. Check the emergency stop switch assembly.

Check whether the engine stops when the emergency stop switch assembly is pressed or the motor stop safety rope is pulled out.

6. Check the cooling water observation hole.

When the engine is running, check whether the cooling water is flowing out of the cooling water observation hole.



1. Cooling water observation hole

7. Running-in operation.

- ① The 1st hour: Run the engine at 2000 rpm or at about half the throttle.
- ② The 2nd hour: Run the engine at 3000 rpm or at about 3/4 of the throttle.
- ③ Next 8 hours: Avoid running the motor at full throttle for 5 consecutive minutes.

8. Check after running-in operation

- ① Check the gear oil for water.
- ② Check the fuel oil pipeline for leaks.
- ③ After running-in operation, run the engine at idle speed and flush the cooling water channel with fresh water using flushing tools.

9. After running-in operation, check the idle speed of the engine.

- ① Preheat the engine for 5 minutes.
- ② Use a tachometer to measure the idle speed of the engine.

Make corresponding adjustment if it does not conform to the specified value. Idle value: 750 ~ 850rpm.

③ Turn the throttle stop screw clockwise or counterclockwise until the specified idle speed is reached.

④ After adjusting the idle speed, speed up several times to check the stability of the engine.


Attention:

Idle speed adjustment needs to be carried out by qualified maintenance personnel using professional equipment; Random adjustment may cause starting difficulties, weakness, jitter and other faults of the engine.

Special Tools and Testing Equipment

Various special tools and testing equipment will be used in the repair and maintenance of outboard motors. Skilled and correct use of these tools and equipment can help improve your work efficiency avoid damage to personnel and outboard motors.

Special tools:



Clearance gauge




Piston slideway



Flywheel gripper and flywheel puller



Oil filter spanner



Bearing puller



Valve spring compressor kit



Bearing mounting tool
Lower unit



Oil seal mounting tool
Lower unit



Needle bearing mounting tool
Lower unit



Shell cover tool
Lower unit



Needle bearing tool
Lower unit



Drive shaft bearing
cover mounting tool




Drive shaft bearing
mounting tool



Drive shaft seat oil seal
mounting kit



Forwarder gear bearing
mounting tool kit



Drive shaft spline sleeve



Pinion nut wrench

Testing equipment:



Digital tachometer



Digital multimeter



Peak voltage adapter

Decomposition Schematic Diagram and Symbolic Description

Decomposition schematic description

| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | REMARKS 备注 |
|-------------|------------------|-------------------------|-------------------------|-----------|---------------|
| 1 | F25-00000100 | 机油尺组件 | PLUG, OIL LEVEL | 1 | |
| 2 | F25-02010100 | 溢流阀组件 | RELIEF VALVE AUY | 1 | |
| 3 | F25-02010006 | 溢流阀垫片 | GASKET, RELIEF VALVE | 1 | |
| 4 | GB/T97.1-2000 | 平垫圈6 | WASHER , PLAIN | 15 | |
| 5 | GB/T5783-2000 | 六角螺栓M6x25 | HEXAGON BOLT | 13 | |
| 6 | F25-02010200 | 粗滤器组件 | STRAINER, OIL | 1 | |
| 7 | GB/T5783-2000 | 六角螺栓M6x16 | HEXAGON BOLT | 2 | |
| 8 | F25-00000014 | 定位销8x12 | PIN, DOWEL | 2 | |
| 9 | F25-02000006 | 油底壳 | OIL SUMP | 1 | |
| 10 | F25-02010007 | 排气歧管座垫 | HEXAGON BOLT | 1 | |
| 11 | F15-00000006 | 定位销6x12 | PIN, DOWEL | 2 | |
| 12 | F15-04000003 | 放油螺塞垫片 | GASKET | 1 | |
| 13 | F15-04000002 | 放油螺塞 | BOLT, OIL DRAIN | 1 | |
| 14 | F25-02000007 | 放油口胶套 | JACKET, OIL DRAIN | 1 | |
| 15 | F25-02010005 | 阳极 | ANODE | 1 | |
| 16 | F15-07010009 | 阳极密封圈 | SEAL. ANODE | 1 | |
| 17 | F15-07010011 | 阳极盖板 | COVER , ANODE | 1 | |
| 18 | GB/T97.1-1985 | 平垫圈5 | WASHER | 1 | |
| 19 | GB/T5783-2000 | 六角螺栓M5x12 | BOLT | 1 | |
| 20 | GB/T5783-2000 | 六角螺栓M6x20 | BOLT | 1 | |
| 21 | GB/T97.1-1985 | 平垫圈6 | WASHER | 1 | |
| 22 | F15-07010012 | 阳极锁止片 | PLATE , ANODE | 1 | |

① Decomposition schematic diagram of parts.

② Thread specification and specified torque.

③ Application point of oil, sealant or locker.

④ Parts list

Symbolic description

| | | | | |
|------------------|-------------------------|--------------------------|--------------------------|---------------|
| | | | | |
| Apply engine oil | Apply waterproof grease | Apply thread locker 1277 | Apply thread locker 1243 | Apply sealant |

Specifications

Parameters of Outboard Motor

| Item | | Data | | Item | | Data | | |
|---------------------|-------------------------------|---------------------|--|---------|------------------|----------------------|----------------------------------|----------------------------|
| Dimension | Overall length (BE/FE) | | 1383/713 mm | | Engine | Spark plug | | DPR7EA-9 (NGK)) |
| | Overall width | | 427 mm | | | Cooling system | | Water cooling |
| | Overall height | D/T | 1435 mm | | | Exhaust system | | Through the propeller hub |
| | | CD/CT | 1476 mm | | | Lubrication system | | Pressure lubrication |
| | Height of stem board | | 508 mm | | | Fuel type | | Ordinary unleaded gasoline |
| Weight | BEL-D/BEL-CD | | 113 kg/126.5 kg | | Fuel grade | | PON86 | |
| | BEL-T/BEL-CT | | 114.5 kg/128 kg | | Engine oil type | | Four-stroke engine oil | |
| | FEL-T/FEL-CT | | 113.5 kg/127 kg | | Engine oil grade | API | SE, SF, SG, SH, SJ | |
| Performance | Max. output | F50 | 36.8Kw@5500r/min | | | SAE | 10W30, 10W40 | |
| | | F60 | 44.1Kw@5500r/min | | Engine oil level | | 2.2L (replace filter) | |
| | Full throttle operating range | | 5000~6000 r/min | | Gear oil type | | Hypoid gear oil | |
| | Max. fuel consumption | F50 | 18.5 L/h@6000 r/min | | Gear oil grade | API | GL-4 | |
| | | F60 | 20 L/h@6000 r/min | | | SAE | 90 | |
| | Idle (neutral) | | 800±50 r/min | | Gear oil level | D/T | 0.43L | |
| | Engine type | | In-line four-stroke, overhead cam | | | CD/CT | 0.61L | |
| Number of cylinders | | 4 | | Bracket | Tilt raise angle | | 69° | |
| Displacement | | 996 cm ³ | | | Steering angle | | 40°+40° | |
| Bore×Stroke | | 65 mm×75 mm | | | Trim angle | | -4°~20° (when stem board is 12°) | |
| Engine | Compression ratio | | 9.3 | | Drive device | Gear | | F-N-R |
| | Oil supply mode | | Electronically controlled fuel injection | | | Transmission ratio | D/T | 2.08 |
| | Control mode | BE | Steering handle | | | | CD/CT | 2.0 |
| | | FE | Remote control | | | Gear type | | Spiral bevel gear |
| | Starting mode | | Electrical starting | | | Clutch type | | Claw clutch |
| | Ignition system | | ECU | | | Propeller shaft type | | Spline |
| | Ignition timing | TDC | 2°±0.5° | | | Propeller direction | | Clockwise (rear view) |
| | | BTDC | 25°±0.5° | | | | | |

Repair Information

Engine

| Item | | Data | Item | | Data | | | |
|----------------|--|----------------|------------------------------|-------------------------------------|---|------------------------------|------------------|-----------------|
| Drive device | Min. compression pressure | 840 kPa | Diameter of piston | | 64.950~64.965mm | | | |
| | Lubricating oil pressure | 100 kPa | Height of measuring point | | 5mm (from bottom of piston) | | | |
| Cylinder head | Bending limit | 0.03mm | Piston-to-cylinder clearance | | 0.035~0.065mm | | | |
| | Inside diameter of camshaft bore | 37.00~37.02mm | Piston pin hole aperture | | 15.974~15.985mm | | | |
| | Inner diameter of shaft hole of rocker arm | 16.000~16.01mm | Piston pin outer diameter | | 15.965~15.970mm | | | |
| Cylinder block | Cylinder bore | 65.00~65.013mm | Piston ring | Top ring | Thickness | 1.17~1.19mm | | |
| | Wear limit | 65.1mm | | | Width of end face | 2.25~2.4mm | | |
| | Taper limit | 0.08mm | | | End gap | 0.15~0.30mm | | |
| | Roundness limit | 0.05mm | | Backlash | 0.02~0.06mm | | | |
| | Second ring | Thickness | 1.47~1.49mm | Valve spring | Free length | | 40.0mm | |
| | | | Width of end face | | 2.60~2.80mm | Min. free length | | 38.4mm |
| | | | End gap | | 0.30~0.50mm | Tilt limit | | 1.7mm |
| | | | Backlash | | 0.02~0.06mm | Inner diameter of small end | | 15.985~15.998mm |
| | Oil ring | Thickness | 2.36~2.48mm | Connecting rod | Inner diameter of big end | | 36.000~36.016mm | |
| | | | Width of end face | | 2.75mm | Large head oil clearance | | 0.020~0.052mm |
| | | | End gap | | 0.20~0.70mm | Thickness of big-end bearing | A black | 1.496~1.490 mm |
| | | | Backlash | | 0.04~0.18mm | | B brown | 1.490~1.484mm |
| Camshaft | Height | Intake cam | 30.83~31.03mm | Oil pump | Type | | Cycloid pump | |
| | | Exhaust cam | 30.83~31.03mm | | Pressure relief valve opening pressure | | 382~442 kPa | |
| | Diameter of base circle | | 25.90~26.10mm | | Clearance between outer rotor and casing | | 0.09~0.15 mm | |
| | Journal diameter | | 36.935~36.955 mm | | Clearance between outer rotor and inner rotor | | 0.12 mm | |
| | Roundness limit | | 0.03mm | | Clearance between rotor and cover | | 0.03~0.08 mm | |
| | Clearance between journal and oil | | 0.045~0.085mm | Diameter of crankshaft main journal | | 42.984~43.000 mm | | |
| Valve | Valve clearance (Cold state) | Intake valve | 0.15~0.25mm | Crankshaft | Crank pin diameter | | 32.984~33.000 mm | |
| | | Exhaust valve | 0.25~0.35mm | | Crank pin width | | 21.00~21.07mm | |
| | Valve cone Width | Intake valve | 1.84~2.97mm | | Crankshaft big-end backlash | | 0.05~0.22mm | |
| | | Exhaust valve | 1.98~3.11mm | | Roundness limit | | 0.05mm | |
| | Width of contact with race | | 0.9~1.1mm | | Thermostat | Opening temperature | | 58~62°C |
| | Edge thickness | Intake valve | 0.8mm | Full open temperature | | 70°C | | |
| | | Exhaust valve | 0.9mm | Mini. opening height of valve | | 3mm | | |
| | Head diameter | Intake valve | 31.9~32.1mm | Fuel pump | Displacement | | 70 L@6000 r/min | |
| | | Exhaust valve | 25.9~26.1mm | | Pressure | | 49kPa | |
| | Rod diameter | Intake valve | 5.475~5.490mm | | Plunger stroke | | 5.85~9.65 mm | |
| | | Exhaust valve | 5.460~5.475mm | Crankcase | Inner diameter of crankshaft main journal | | 46.000~46.024mm | |
| | Inner diameter of pipe | | 5.500~5.512mm | | Clearance between crankshaft main journal and | | 0.012~0.044mm | |

| | | | | | | |
|--|---|---------------|--|--------------------------------------|---------|----------------|
| | | | | oil | | |
| | Clearance between pipe and valve stem clearance | 0.025~0.052mm | | Thickness of crankshaft bearing bush | A black | 1.500~1.494 mm |
| | Valve stem roundness limit | 0.03mm | | | B brown | 1.494~1.488mm |

Measurement conditions:
Ambient temperature 20 °C.

Lower casing Installation

| Item | | Data | Item | Data |
|----------|------------------------|----------------|--------------------|--|
| Backlash | Pinion to spur gear | 0.18~0.54mm | Optional gear shim | 0.10,0.12,0.15,0.18, 0.30,0.40,0.50 mm |
| | Pinion to reverse gear | 0.71 ~ 1.07 mm | | |

Electrical System

Ignition and Ignition Control System

| Item | | Data | Item | | Data |
|-----------------------------|----------------------------|------------------|---|--------------------------|----------------------|
| Ignition timing | At idle speed | TDC 2°±0.5° | Magneto resistance (Green-Green) | | 0.59±0.1Ω |
| | Optional gear filler plate | BTDC 25°±0.5° | Peak output of electronic igniter | Secondary output voltage | ≥ 34KV |
| Spark plug clearance | | 0.8~0.9mm | | Voltage | Primary resistance |
| Trigger coil | Peak voltage | ≥13 V@1000 r/min | Rectifier regulator output peak voltmeter | | Secondary resistance |
| | Resistance* | 260~290 Ω | | 1500 r/min (no load) | 41.9 V |
| Magneto output peak voltage | 1500 r/min (no load) | 47.2 V | 3500 r/min (no load) | | 99.8 V |
| | 3500 r/min (no load) | 106 V | | | |

* Data for information only


Locking Torque Specified Torque

| Position | | Name | Thread specification | Torque | |
|----------|-----------------------|----------------------------|----------------------|---------|--------|
| Engine | Spark plug | | — | 18 Nm | |
| | Flywheel | | Nut | M20 | 160 Nm |
| | Cylinder head | 1 st tightening | Bolt | M9 | 23Nm |
| | | 2 nd tightening | | | 47 Nm |
| | | 1 st tightening | Bolt | M6 | 6 Nm |
| | | 2 nd tightening | | | 12 Nm |
| | Oil filter | | — | — | 18 Nm |
| | Oil filter stud | | — | — | 40 Nm |
| | Lock nut (rocker arm) | | Nut | M6x0.75 | 14 Nm |
| | Engine assembly | | Bolt | M8 | 21 Nm |
| | Exhaust cover plate | 1 st tightening | Bolt | M6 | 6 Nm |
| | | 2 nd tightening | | | 12 Nm |
| | Thermostat cover | | Bolt | M6 | 7Nm |
| | Crankc | 1 st tightening | Bolt | M8 | 15 Nm |

| | | | | | |
|----------------------|-------------------------------|----------------------------|------------------|-------|--------|
| | ase | 2 nd tightening | | | 30 Nm |
| | | 1 st tightening | Bolt | M6 | 6 Nm |
| | | 2 nd tightening | | | 12 Nm |
| | Connec ting rod | 1 st tightening | Bolt | M6 | 6 Nm |
| | | 2 nd tightening | | | 17 Nm |
| Driven pulley | | Bolt | M10 | 38 Nm | |
| Lower casing unit | Lower casing assembly | | Bolt | M10 | 40Nm |
| | Ring nut | | — | — | 105Nm |
| | Water inlet | | Screw | M5 | 5 Nm |
| | Oil drain bolt | | Bolt | — | 7Nm |
| | Oil check hole | | Bolt | — | 7 Nm |
| | Pinion gear | | Nut | M22 | 95 Nm |
| | Propeller nut | | Nut | M14 | 35 Nm |
| Upper Casing | Steering handle | | Nut | M10 | 10 Nm |
| | Steering handle | | Self-locking nut | M10 | 22 Nm |
| | Exhaust manifold | | Bolt | M6 | 10 Nm |
| | Throttle grip | | Screw | M5 | 3 Nm |
| | Shift linkage bracket | | Bolt | M6 | 10 Nm |
| | Gear spring piece | | Bolt | M6 | 10 Nm |
| | Bottom cover flat | | Bolt | M6 | 10 Nm |
| | Clamp bracket | | Self-locking nut | — | 45 Nm |
| | Oil drain bolt | | Bolt | M14 | 27 Nm |
| Tilting system | Inclined cylinder end | | Screw | — | 90 Nm |
| | Tilting motor | | Screw | M5 | 4 Nm |
| | Fuel tank cap | | — | — | 6.5 Nm |
| | Trim cylinder end | | Screw | — | 80 Nm |
| | Tilt piston | | Bolt | M12 | 61 Nm |
| | Pressure relief valve bracket | | Bolt | M5 | 5.3 Nm |
| | Gear pump assembly | | Bolt | M6 | 6.5 Nm |
| | Gear pump bracket | | Bolt | M5 | 5.3 Nm |
| Electrical system | Trigger coil | | Screw | — | 4 Nm |
| | Starter motor | Nut | — | 30 Nm | |
| | | Bolt | M8 | 30 Nm | |
| | Starter motor terminal | | Nut | — | 7 Nm |
| Magneto coil | | Bolt | M6 | 7 Nm | |



General Torque

| Nut a | Bolt b | Torque |
|-------|--------|--------|
| 8mm | M5 | 5Nm |
| 10mm | M6 | 8 Nm |
| 12mm | M8 | 18 Nm |
| 14mm | M10 | 36 Nm |
| 17mm | M12 | 43 Nm |





Dimensions


Outline Dimension(D/T model)



Outline Dimension (CD/CT model)



Mounting dimensions of clamp bracket



Basic Maintenance Maintenance Interval Chart

| Item | Content | Initial maintenance | | General maintenance interval | |
|--------------------------|----------------------|-----------------------|-----------------------|------------------------------|-----------------------|
| | | 10 hours (1 month) | 50 hours (3 month) | 100 hours (6 month) | 200 hours (1 year) |
| Anode | Check/replace | | ○ | ○ | |
| Anode (internal) | Check/replace | | | | ○ |
| Cooling water channel | Clean | | ○ | ○ | |
| Spark plug | Clean/adjust/replace | ○ | | | ○ |
| Grease filling point | Add grease | | | ○ | |
| Fuel filter | Check/replace | ○ | ○ | ○ | |
| Fuel system | Check | ○ | ○ | ○ | |
| Fuel tank | Check/clean | | | | ○ |
| Idle speed | Check/adjust | ○ | | ○ | |
| Engine oil | Replace | ○ | | ○ | |
| Oil filter | Replace | | | | ○ |
| Valve clearance (OHC) | Check/adjust | ○ | | ○ | |
| Ignition timing | Check | ○ | | ○ | |
| Thermostat | Check | | | | ○ |
| Gear oil | Replace | ○ | | ○ | |
| Water pump | Check | | | | ○ |
| Propeller and cotter pin | Check/replace | | ○ | ○ | |
| Timing band | Check/replace | | | ○ | ○ |
| Throttle cable | Check/adjust | | | | ○ |
| Shift lever/shift cable | Check/adjust | | | | ○ |

Attention:

Flush the outboard motor with fresh water immediately after operation in brine, sewage or muddy water.

If leaded petrol is frequently used, check valves and related parts every 100 hours.


Replace the timing band every 1000 hours (5 years).

Fuel System

1. Check the fuel tank, fuel pump and fuel pipe.

Check the fuel tank, fuel pump and fuel pipe for leaks or damage and replace it if necessary.

Check the fuel oil filter core on the oil tank for any dirt, and clean or replace it if necessary.



2. Check the fuel joint.

Check the fuel joint for cracks, leaks or damage. Replace it if necessary.

3. Check the fuel filter.

Check whether the fuel filter is cracked or damaged, and check whether there is any dirt in the fuel filter.

If yes, replace the fuel filter.





Attention:

Wipe up the spilled fuel.

Engine

Engine Oil Level

1. Remove the oil dipstick and check whether the oil level is between the upper and lower marks of the oil dipstick.



1. Oil dipstick 2. High position mark 3. Low position mark

2. Drain the oil if it is above the high position mark, and add oil if it is below the low position mark.

Attention:

Turn off the engine after running it and let it stand for several minutes. Check the oil level again with the oil dipstick.

If the oil level is not within the specified range, add/drain oil to the specified value.

Replace Engine Oil

1. Remove the oil cap, oil drain bolt and bolt gasket; Drain the oil out.



2. Install a new bolt pad and install the oil drain bolt.
3. Add engine oil through the oil port.
Engine oil level: 2.0 L (The oil filter is not replaced)
2.2 L (oil filter is changed)
Oil type: API: SE, SF, SG, SH, SJ or SAE: 10W30, 10W40
4. Install oil filter cap.
5. Check oil level.

Valve Clearance

1. Remove the engine stop safety cable from the emergency stop switch assembly and remove the spark plug cap from the spark plug.
2. Remove belt cover.
3. Remove the fuel pump and cylinder head cover.
4. Check the timing band for slack, aging, or damage. Replace it if necessary.
5. Turn the flywheel clockwise. Align "1" on the driven pulley with "▼" on the cylinder head.
Check the intake valve clearance of cylinders 1# and 2# and the exhaust valve clearance of cylinders 1# and 3#. Correct it if necessary.
6. Turn the flywheel 180° clockwise; Align "●" on the driven pulley with "▼" on the cylinder head.
7. Check the intake valve clearance of cylinders 3# and 4# and the exhaust valve clearance of cylinders 2# and 4#. Correct it if necessary.

Attention:

It is strictly prohibited to turn the flywheel counterclockwise to avoid damage to the valve system.

Note:

Adjust valve clearance when the engine is cold.

| | | |
|---------------------------------|---------------|-------------|
| Valve clearance (Cold state) | Intake valve | 0.15~0.25mm |
| | Exhaust valve | 0.25~0.35mm |


8. Loosen the lock nut and turn the adjusting screw until the specified valve clearance is reached.
Note:
Turn the adjusting screw clockwise to reduce the valve clearance.
Turn the adjusting screw counterclockwise to increase the valve clearance.
9. Reinstall the removed parts.

Spark Plug

1. Remove the spark plug cap and then remove the spark plug.
2. Remove carbon deposits from the spark plug electrodes.
3. Check whether the electrodes are corroded, whether there is deposit, and whether the gasket is damaged. Replace the spark plugs if necessary.

Spark plug model: DPR7EA-9

4. Check whether the electrode gap meets the specified value; Replace the spark plugs if necessary.




5. Install the spark plug and tighten it with a spark plug wrench according to the specified torque.
Specified torque: 18 Nm

Control System


Throttle Cable

1. Place the throttle grip in the closed position; Put the shift lever to the neutral position for the front operation model.
2. Check whether the roller on the driven pulley of the throttle actuator can be observed in the observation window on the driving pulley of the throttle actuator; If the roller cannot be observed, adjust the length of the cable joint.



1. Driving pulley of throttle actuator; 2. Observation window.

3. Remove the cotter pin, remove the cable connector and loosen the lock nut of the cable joint.



1. Cotter pin 2. Cable joint 3. Lock nut

4. Adjust the screw-in depth of the joint so that the joint hole is aligned with the pin of the throttle actuator driving pulley.


Attention:

Cable joints must be screwed in more than 8mm.


5. Fit the cotter pin and screw the lock nut.

Shift Operation

1. Check whether the gear shifting operation is smooth;
2. Place the shift lever in neutral position.
3. Observe that the pin on the swing rod is aligned with the mark on the swing rod seat of throttle.



1. Swing rod seat of throttle; 2. Mark.




4. If the pin is not aligned with the mark, adjust the screw-in depth of the cable joint. (Refer to the adjustment method of cable joint of throttle)

Lower Casing Unit Gear Oil

Check gear oil level

Remove the oil level plug screw. If there is oil spill, the oil level is correct. If there is no oil spill, add oil to it.



1. Oil level plug screw

Change gear oil

1. Place the outboard motor upright.
2. Place a container with sufficient capacity under the outboard motor.
3. Remove the oil drain screw, and then remove the oil level plug screw to drain the gear oil.



1. Oil level plug screw 2. Oil drain screw

4. Inject gear oil into the oil drain screw hole using the pressure filling device.
5. When gear oil spills out of the oil level plug hole, install the oil level plug screw.
6. Install the oil drain screw; Wipe off the spilled gear oil.

Note:

Check the drained gear oil. If gear oil is emulsified, check the seal and replace it if necessary. If there are metal debris in the gear oil, check the gears and bearings.

Attention:

A new drain screw gasket must be replaced every time.

Air tightness Inspection of Lower casing Unit

Connect the leak detection device to the oil level plug hole to check the air tightness of the Lower casing unit. If the pressure drops (the pressure is 1kg/cm^3), check the oil seal and other components.

General maintenance

Anode


Check the anodes of the Lower casing unit and the engine (installed on the thermostat cover); Remove oil and scale; If damage or corrosion exceeds 1/2, replace the anode.

Attention:


Do not apply oil or paint to the anode to avoid failure of the anode.

Lubrication Point

1. Fill or apply waterproof grease to the parts shown in the figure with an oil gun.



2. Apply anti-corrosion lubricating oil to the propeller shaft.



Cooling Water Channel

1. Check the inlet of the cooling water channel for blockage. Clean it if necessary.



1. Inlet of cooling water channel

2. Place the outboard motor in the water to ensure that the water level is above the anti-swirl plate and start the engine.
3. Check whether there is cooling water flowing out from the observation hole. If there is no water or the water flow is intermittent, check the cooling water channel in the outboard motor.



1. Cooling water observation hole
Thermostat

1. Remove the thermostat cover, and then remove the thermostat.

2. Hang the thermostat in a container with water.
3. Heat the container.
4. Check the opening of thermostat valve at the specified water temperature; If it does not conform to the specifications, replace it.

| Water temperature | Opening height of valve |
|-------------------|-------------------------|
| Below 60 °C | Not open |
| Above 70 °C | More than 3mm |

5. Install the thermostat and thermostat cover and tighten the bolts to the specified values.

Propeller

Inspect the propeller blades and internal splines for rupture, damage or wear. Replace it if necessary.

Electrical System

Attention:


Please be careful when monitoring and repairing the ignition system Do not place your hands, clothes, hair or accessories close to the running flywheel.

Test the ignition coil on an insulated workbench to prevent electric leakage and electric shock.


When the engine is running, do not touch the ignition coil or spark plug to avoid electric shock. Make sure that the wire is away from the running flywheel to prevent the wire from being cut off or the wire insulation from being worn.

When replacing fasteners (nuts and bolts), please use the parts provided by the manufacturer or of the same material and strength and tighten them with specified torque.


Decomposition Schematic Diagram



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|---------------------------------|-------------------------------------|-----------|--|--|--|--|---------------|
| 1 | F60-05000041 | 飞轮罩 | COVER, FLYWHEEL | 1 | | | | | |
| 2 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 4 | | | | | |
| 3 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 11 | | | | | |
| 4 | F25-05000026 | 飞轮螺母 | FLYWHEEL NUT | 1 | | | | | |
| 5 | F25-05000025 | 飞轮螺母垫圈 | WASHER, FLYWHEEL NUT | 1 | | | | | |
| 6 | F60-05000300 | 飞轮 | FLYWHEEL | 1 | | | | | |
| 7 | GB/T5783-M6x30 | 六角螺栓 M6x30 | BOLT M6x30 | 7 | | | | | |
| 8 | F40-05000600EI | 磁电机线圈组件 | MAGNETO COIL ASSY | 1 | | | | | |
| 9 | F40-05000034 | 线圈支架 | BRACKET, COIL | 1 | | | | | |
| 10 | F8-00000005 | 空心定位销 $\varnothing 8 \times 10$ | DOWEL PIN $\varnothing 8 \times 10$ | 2 | | | | | |
| 11 | F25-05000024 | 飞轮半圆键 | WOODRUFF KEY, FLYWHEEL | 1 | | | | | |
| 12 | GB/T5783-M5x12 | 六角螺栓 M5x12 | BOLT M5x12 | 2 | | | | | |
| 13 | GB/T97.1-5 | 平垫圈 5 | WASHER 5 | 2 | | | | | |
| 14 | F60-05000200 | 触发线圈组件 | PULSER COIL ASSY | 1 | | | | | |
| 15 | F60-05000052 | 触发器垫板 | PLATE, PULSER COIL | 1 | | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|-----------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 8 | | | | | |
| 2 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 12 | | | | | |
| 3 | F40-05091401EI | 主继电器固定支架 | BRACKET, MAIN RELAY | 2 | | | | | |
| 4 | F40-05091402EI | 主继电器减震圈 | DAMPER, MAIN RELAY | 2 | | | | | |
| 5 | T40-05000028 | 点火器垫管 | TUBE, IGNITER | 2 | | | | | |
| 6 | F40-05000060EI | 主继电器固定板 | FIXED PLATE, MAIN RELAY | 1 | | | | | |
| 7 | F40-05091400EI | 主继电器 | MAIN RELAY | 2 | | | | | |
| 8 | GB/T6170-M6 | 六角螺母 M6 | NUT M6 | 2 | | | | | |
| 9 | GB/T93-6 | 弹性垫圈 6 | SPRING WASHER 6 | 2 | | | | | |
| 10 | GB/T5782-M6x35 | 六角螺栓 M6x35 | BOLT M6x35 | 4 | | | | | |
| 11 | F40-05000059EI | 线卡 C | CLAMP C | 1 | | | | | |
| 12 | F40-05000003 | 线卡 | CLAMP | 3 | | | | | |
| 13 | GB/T5783-M6x10 | 六角螺栓 M6x10 | BOLT M6x10 | 1 | | | | | |
| 14 | F40-05000500EI | 整流器组件 | RECTIFIER ASSY | 1 | | | | | |
| 15 | F40-05090700EI | 水温传感器 | SENSOR, WATER TEMPERATURE | 1 | | | | | |
| 16 | F40-05000042EI | 机油压力传感器 | OIL PRESSURE SENSOR | 1 | | | | | |
| 17 | F60-05000601 | 高压线 | IGNITION COIL | 4 | | | | | |
| 18 | GB/T96-6 | 大垫圈 6 | WASHER 6 | 2 | | | | | |
| 19 | F60-05000600 | 集成高压包 | IGNITION COIL ASSY | 1 | | | | | |
| 20 | F60-05000023 | 高压包固定架 | PLATE, IGNITION COIL ASSY | 1 | | | | | |
| 21 | F15-07000021 | 进气消音器垫管 | BUSHING, INTAKE SILENCER | 3 | | | | | |
| 22 | F8-05000007 | 减震圈 | DAMPER | 3 | | | | | |
| 23 | F60-05000031 | 固定板支架 | BRACKET, FIXED PLATE | 1 | | | | | |
| 24 | F8-05000021 | 大垫片 | WASHER | 3 | | | | | |
| 25 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 3 | | | | | |
| 26 | F40-05000009-1EI | 模块固定板 | FIXED PLATE, ECU | 1 | | | | | |
| 27 | HDB-6x1.5 | 扎带固定座 | FIXED SEAT, CLAMP | 4 | | | | | |
| 28 | GB/T5783-M6x12 | 六角螺栓 M6x12 | BOLT M6x12 | 2 | | | | | |
| 29 | F60-05001000 | ECU 模块 | ECU | 1 | | | | | |
| 30 | F40-05000049EI | 碳罐电磁阀固定板 | FIXED PLATE, MAGNETIC VALVE | 1 | | | | | |
| 31 | F40-05091500EI | 碳罐电磁阀 | MAGNETIC VALVE, CARBON POT | 1 | | | | | |
| 32 | F60-05000036 | 继电器引出线(黑) | CONNECT LINE(BLACK), RELAY | 1 | | | | | |
| 33 | T85-05030003 | 继电器引出线(棕) | CONNECT LINE(BROWN), RELAY | 1 | | | | | |
| 34 | F40-05030500EI | 点火线束组件 | C. D. I CABLE ASSY | 1 | | | | | FOR FW |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|---------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 5 | | | | | |
| 2 | GB/T5783-M6x10 | 六角螺栓 M6x10 | BOLT M6x10 | 2 | | | | | |
| 3 | F60-05000800 | 液压起翘线束 | CONNECTION LINE, TILT | 1 | | | | | FOR FE-T/BE-T |
| 4 | T85-05030200 | 继电器组件 | RELAY ASSY | 1 | | | | | |
| 5 | F15-05170501W | 电源连接线护套 | JACKET | 2 | | | | | |
| 6 | GB/T 6170 — M6 | 六角螺母 M6 (镀银) | NUT, SILVERING | 2 | | | | | |
| 7 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 2 | | | | | |
| 8 | F40-03000013EI | 起翘继电器固定架 | FIXED BRACKET, TILT RELAY | 1 | | | | | |
| 9 | GB/T5783-M6x12 | 六角螺栓 M6x12 | BOLT M6x12 | 2 | | | | | |
| 10 | T85-05030002 | 继电器连接线(红) | CONNECT LINE(RED), RELAY | 1 | | | | | |
| 11 | F25-05170202W | 电源连接线护套 B | JACKET B | 3 | | | | | |
| 12 | GB/T6170-M6 | 六角铜螺母 M6 | NUT M6(COPPER) | 3 | | | | | |
| 13 | GB/T97.1-6 | 铜垫圈 6 | WASHER 6(COPPER) | 6 | | | | | |
| 14 | F15-07150300W | 启动电机继电器 | RELAY, MOTOR | 1 | | | | | |
| 15 | F15-05170301W | 继电器护套 | JACKET, RELAY | 1 | | | | | |
| 16 | T60-03000300W | 继电器固定板组件 | BRACKET, RELAY | 1 | | | | | |
| 17 | T85-05000022 | 电机连接线 | CONNECTION LINE, MOTOR | 1 | | | | | |
| 18 | F60-05000900 | 模块控制线束 | C. D. I LINE ASSY | 1 | | | | | |
| 19 | F40-05001000-1EI | 保险丝(40A) | FUSE WIRE (40A) | 1 | | | | | |
| | F40-05001000-2EI | 保险丝(20A) | FUSE WIRE (20A) | 1 | | | | | |
| | F40-05001000-3EI | 保险丝(15A) | FUSE WIRE (15A) | 1 | | | | | |
| | F40-05001000-4EI | 保险丝(7.5A) | FUSE WIRE (7.5A) | 1 | | | | | |
| 20 | T85-05000023 | 电源连接线 | CONNECTION LINE, POWER | 1 | | | | | |
| 21 | F25-05170201W | 电源连接线护套 A | JACKET A | 1 | | | | | |
| 22 | GB/T6170- M8 | 六角螺母 M8 | NUT M8 | 1 | | | | | |
| 23 | F25-05170001W | 电机固定螺栓 M8 | FIXATION BOLT , MOTOR | 1 | | | | | |
| 24 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 3 | | | | | |
| 25 | GB/T5783-M8x45 | 六角螺栓 M8x45 | BOLT M8x45 | 1 | | | | | |
| 26 | F60-05000042 | 启动电机螺钉 | BOLT, MOTOR | 1 | | | | | |
| 27 | F60-05000500 | 启动电机 | STARTING MOTOR | 1 | | | | | |

Wiring Diagram




Back-operation electrical starting



Front-operation electrical starting

Spark Plug Ignition

1. Remove the spark plug cap from the spark plug.



1. Spark plug cap; 2. Spark plug

2. Connect the ignition detector to the spark plug cap.
3. Start the engine and observe the spark through the discharge window of the detector.

⚠ Warning:

Do not touch any joint of the detector lead.


Stay away from combustible gases or liquids to avoid accidents caused by spark ignition.

Spark Plug Cap

1. Unscrew spark plug cap. Check the spark plug cap for damage. Replace it if necessary.
2. Install spark plug cap.

Flywheel Maintenance

1. Remove the flywheel nut using the flywheel gripper; Remove the flywheel using the flywheel puller.



2. Check whether the flywheel is damaged and whether the permanent magnet is firm. Replace it if necessary.

Check the Ignition Coil

1. Remove the ignition coil and the spark plug cap.
2. Measure the resistance of the ignition coil. If the specified value is not met, replace it.
Primary resistance: $2.2 \pm 0.22 \Omega$
Secondary resistance $9.84 \pm 0.98 \text{ k}\Omega$

Check the trigger coil

1. Trigger coil peak voltage
Use a digital multimeter and a peak voltage adapter to measure the coil output peak voltage. If it is below the specified value, check the trigger coil resistance.



Digital multimeter



Peak voltage adapter

Pulse coil peak voltage: $\geq 13 \text{ V} @ 1000 \text{ r/min (load)}$

2. Trigger coil resistance

Measure coil resistance. If the specified value is not met, replace it.

Resistance: 260 ~ 290 (the positive electrode of the detector is connected with red/white line and the negative electrode is connected with black line)

Note:

The data are for reference only.

Check the Engine Start Switch

Check the conductivity of the engine start switch. If it is not conductive, replace it.

Note:

See wiring diagram for starting switch status table,

Check the Engine Start Switch

Check the conductivity of the engine stop switch. If it is not conductive, replace it.

Remove locking plate: Conductive

Install locking plate: Not conductive

Press the button: Conductive

Check the Starting Relay

1. Connect the brown lead to the positive electrode of the battery.
2. Connect the black lead to the negative electrode of the battery.
3. Check the conductivity between relay terminals. If it is not conductive, replace the relay.
4. Disconnect the lead connection to the battery and check the conductivity between relay terminals. If it is conductive, replace the relay.

Check the Magneto Coil

Measure the peak voltage of the magneto coil (between the green lines).

Use a digital multimeter and a peak voltage adapter to measure the coil output peak voltage. If it is below the specified value, replace the magneto coil.



| | | |
|---------------------------|----------------------|--------|
| Magneto coil peak voltage | 1500 r/min (no load) | 47.2 V |
| | 3500 r/min (no load) | 106 V |

Check the Rectifier Regulator

Measure the rectifier regulator peak voltage (dc).


Open the circuit of rectifier output (red line and black line) and use a digital multimeter to measure the voltage between the red line and black line at the rectifier regulator output.

If it is below the specified value, check the magneto coil output peak voltage. If the peak output voltage of the magneto coil is higher than the specified value, replace the rectifier regulator.

| | | |
|----------------------------------|----------------------|-------|
| Rectifier regulator peak voltage | 1500 r/min (no load) | 41.9V |
| | 3500 r/min (no load) | 99.8V |

How to Use the Diagnostic Scan Tool

When the engine is running, if the fault light on the bottom cover is always on or the service light is always on/the buzzer is always ringing, it means that there is a fault in the engine. At this time, connect the scan tool with the corresponding detection port on the engine. Through the APP software downloaded in the mobile phone, the operating parameters and fault codes of the engine can be displayed on the mobile phone. Then check the fault code table to determine the fault of the engine and replace the faulty electrical components.



Fault Code Table

| Failure type | Failure item | Code |
|---|---|------|
| Intake pressure failure | Short circuit to ground or open circuit in intake pressure sensor line | 107 |
| | Short circuit to high level in intake pressure sensor line | 108 |
| Intake air temperature failure | Short circuit to high level in intake air temperature sensor line | 112 |
| | Short circuit to ground or open circuit in intake air temperature sensor line | 113 |
| Water temperature failure | Short circuit to ground in coolant temperature sensor line | 117 |
| | Short circuit to high level in coolant temperature sensor line | 118 |
| Throttle failure | Short circuit to ground in throttle position sensor line | 122 |
| | Short circuit to high level in throttle position sensor line | 123 |
| Oxygen sensor failure | Short circuit to ground in oxygen sensor | 131 |
| | Short circuit to high level in oxygen sensor | 132 |
| Oxygen sensor heating failure | Oxygen heater failure | 135 |
| Fuel injector failure | Nozzle line failure of cylinder 1 | 201 |
| | Nozzle line failure of cylinder 2 | 202 |
| | Nozzle line failure of cylinder 3 | 203 |
| | Nozzle line failure of cylinder 4 | 204 |
| Fuel pump failure | Oil pump relay failure | 230 |
| Crankshaft position sensor failure | Crankshaft position sensor line signal interference | 336 |
| | Crankshaft position sensor line no signal | 337 |
| Ignition coil failure | Ignition coil failure of cylinder 1 | 351 |
| | Ignition coil failure of cylinder 2 | 352 |
| Idle speed failure | Excessive idle speed | 507 |


| | | |
|---|---|-------------|
| | Low idle speed | 506 |
| System voltage failure | Low system voltage | 562 |
| | High system voltage | 563 |
| Failure type | Failure item | Code |
| Fault light | Fault indicator lamp failure | 650 |
| Oil pressure failure | Short circuit to ground in oil pressure sensor line | 523 |
| | Short circuit to high level in oil pressure sensor line | 522 |
| Carbon canister solenoid valve failure | Short circuit to ground in carbon canister solenoid valve | 443 |
| Main relay failure | Main relay failure | 685 |

Fuel System


Attention:

Fuel is a highly flammable and volatile liquid. Fuel leakage can cause fire and explosion. Do not attempt to start the engine before determining that the components of the fuel system are connected or installed. After completing all repair steps, apply pressure to the fuel system for a short period of time to check for leaks.


Decomposition Schematic Diagram



| SX. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|--------------------------|---------------------------|----------------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T5783-M6x14 | 六角螺栓 M6x14 | BOLT M6x14 | 1 | | | | | |
| 2 | GB/T93-6 | 弹性垫圈 6 | SPRING-WASHER 6 | 1 | | | | | |
| 3 | GB/T6170-M8 | 六角螺母 M8 | NUT M8 | 1 | | | | | |
| 4 | F40-05000036 | 滤油杯支架 | BRACKET , FILTER CUP | 1 | | | | | |
| 5 | T85-05000300 | 滤油杯组件 | FILTER CUP ASSY | 1 | | | | | |
| 6 | F15-07080001 | 滤网架 | ELEMENT, FILTER | 1 | | | | | |
| 7 | T85-05000302 | 浮子 | FLOATER | 1 | | | | | |
| 8 | GB/T3452.1- ∅32.5x1.8 | 滤油杯密封圈 ∅32.5 x1.8 | SEAL, FILTER CUP | 1 | | | | | |
| 9 | T85-05000301 | 滤杯 | CUP, FILTER | 1 | | | | | |
| 10 | F4-04000030 | 油管夹簧 B | SPRING , FUEL PIPE "B" | 6 | | | | | |
| 11 | F60-03000012 | 燃油管 A ∅5x ∅10x650 (EPA) | FUEL P IPE A ∅5x ∅10x650 (EPA) | 1 | | | | | EFI |
| 12 | F60-05000051E1 | 燃油定型管 (EPA) | FUEL P IPE (EPA) | 1 | | | | | EFI |
| 13 | S7133-13.3 | 单耳无极卡箍 13.3 | SINGLE LUG CLAMP | 1 | | | | | |
| 14 | F60-05000006 | 燃油管 B ∅6x ∅12.5x730(EPA) | FUEL P IPE B ∅6x ∅12.5x730(EPA) | 1 | | | | | EFI |
| 15 | GB/T3452.1-25x3.0 | O形圈 25x3.0 | O-RING 25x3.0 | 1 | | | | | |
| 16 | GB/T5783-M6x30 | 六角螺栓 M6x30 | BOLT M6x30 | 2 | | | | | |
| 17 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 2 | | | | | |
| 18 | F40-05050000 | 燃油泵组件 | FUEL PUMP ASSY | 1 | | | | | |
| 19 | F25-05130004 | 柱塞 | PLUNGER | 1 | | | | | |
| 20 | F25-05130003 | 柱塞弹簧 | SPRING , PLUNGER | 1 | | | | | |
| 21 | F25-05130001 | 燃油泵座 | SEAT, FUEL PUMP | 1 | | | | | |
| 22 | GB/T6170-M5 | 六角螺母 M5 | NUT M5 | 4 | | | | | |
| 23 | F25-05130002 | 隔膜弹簧 | SPRING, DIAPHRAGM | 1 | | | | | |
| 24 | F25-05130008 | 滚针 φ4x16.5 | ROLLER NEEDLE φ4x16.5 | 1 | | | | | |
| 25 | F25-05130100 | 隔膜轴组件 | DIAPHRAGM SHAFT ASSY | 1 | | | | | |
| 26 | F4-04090011 | 阀片螺钉 M3x6 | SCREW M3x6 | 2 | | | | | |
| 27 | F4-04090005 | 单向阀片 | UNILATERAL PLATE | 2 | | | | | |
| 28 | F40-05050200 | 燃油泵壳组件 | FUEL PUMP SHELL ASSY | 1 | | | | | |
| 29 | F25-05130005 | 上隔膜 | UPPER DIAPHRAGM | 1 | | | | | |
| 30 | F25-05130006 | 燃油泵盖密封圈 | SEAL , FUEL PUMP | 1 | | | | | |
| 31 | F25-05130007 | 燃油泵盖 | COVER, FUEL PUMP | 1 | | | | | |
| 32 | GB/T818-M5x40 | 十字槽盘头螺钉 M5x40 | SCREW, PAN HEAD M5x40 | 4 | | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|---------------------|--|----------------------------------|-----------|--|--|--|---------------|
| 1 | F60-05000025 | 回气管 C $\varnothing 5x \varnothing 10x260$ | AIR PIPE C | 1 | | | | |
| 2 | T5-04000200 | 单向阀 | CHECK VALVE | 1 | | | | |
| 3 | F60-05000019 | 回气管 C $\varnothing 5x \varnothing 10x60$ (EPA) | AIR PIPE C | 1 | | | | |
| 4 | F60-05000016 | 回气管 B $\varnothing 5x \varnothing 10x270$ | AIR PIPE B | 1 | | | | |
| 5 | F60-05000054 | 塑料三通 $\varnothing 6.5$ | THREE WAY | 1 | | | | |
| 6 | F60-05000053 | 燃油定型管 | FUEL PIPE | 1 | | | | |
| 7 | F40-05100000E1 | 电动燃油泵组件 | OIL PUMP ASSY | 1 | | | | |
| 8 | F40-05010400E1 | 油泵接头组件 | JOINT ASSY, OIL PUMP | 1 | | | | |
| 9 | GB/T3452.1-15.8x3.1 | O型圈 15.8x3.1 | O-RING 15.8x3.1 | 1 | | | | |
| 10 | F40-05100100E1 | 电动燃油泵本体组件 | BODY ASSY, OIL PUMP | 1 | | | | |
| 11 | S7133-13.3 | 单耳无极卡箍 | SINGLE LUG CLAMP | 4 | | | | |
| 12 | F40-05100010E1 | 油泵定型管 A | SHAPED TUBE A, OIL PUMP | 1 | | | | |
| 13 | F40-05100004E1 | 油泵定型管 B | SHAPED TUBE B, OIL PUMP | 1 | | | | |
| 14 | F40-05100202E1 | 检测阀盖帽 | CAP, DETECTION VALVE | 1 | | | | |
| 15 | F40-05100201E1 | 油泵检测阀 | DETECTION VALVE, OIL PUMP | 1 | | | | |
| 16 | F40-05100600E1 | 压力调节阀 | PRESSURE REGULATOR VALVE | 1 | | | | |
| 17 | F40-05100601E1 | 压力调节阀 O形圈 | O-RING, PRESSURE REGULATOR VALVE | 1 | | | | |
| 18 | F40-05100600-1E1 | 压力调节阀尼龙垫圈 | WASHER, PRESSURE REGULATOR VALVE | 2 | | | | |
| 19 | F40-05100602E1 | 泄油导管 | CONDUIT TUBE | 1 | | | | |
| 20 | F40-05100603E1 | 压力阀压板 | PALTE, PRESSURE REGULATOR VALVE | 1 | | | | |
| 21 | GB/T818-M5x12 | 十字槽盘头螺钉 M5x12 | SCREW M5x12 | 2 | | | | |
| 22 | GB/T818-M4x16 | 十字槽盘头螺钉 M4x16 | SCREW M4x16 | 5 | | | | |
| 23 | GB/T93-4 | 弹性垫圈 4 | SPRING WASHER 4 | 5 | | | | |
| 24 | F40-05100301E1 | 针阀 | NEEDLE VALVE | 1 | | | | |
| 25 | F40-05100302E1 | 针阀卡簧 | CLAMP SPRING, NEEDLE VALVE | 1 | | | | |
| 26 | F40-05100003E1 | 挡板 | BAFFLE PLATE | 1 | | | | |
| 27 | GB/T818-M4x8 | 十字槽盘头螺钉 M4x8 | SCREW M4x8 | 4 | | | | |
| 28 | F40-05100001E1 | 浮子 | FLOATER | 1 | | | | |
| 29 | F40-05100002E1 | 浮子销 | PIN, FLOATER | 1 | | | | |
| 30 | F40-05100500E1 | 油泵组件 | OIL PUMP ASSY | 1 | | | | |
| 31 | F40-05100501E1 | 油泵口胶套 | RUBBER SLEEVE, OIL PUMP | 1 | | | | |
| 32 | F40-05100504E1 | 油泵垫块 | PADDING BLOCK, OIL PUMP | 1 | | | | |
| 33 | F40-05100503E1 | 油泵橡胶垫 | RUBBER PAD, OIL PUMP | 1 | | | | |
| 34 | F40-05100502E1 | 油泵滤网 | FILTER NET, OIL PUMP | 1 | | | | |
| 35 | F40-05100704E1 | 油杯密封圈 | SEAL, OIL CAP | 1 | | | | |
| 36 | F40-05100701E1 | 电动燃油泵油杯组件 | OIL CAP, ELECTRIC PUMP | 1 | | | | |
| 37 | F25-05090005 | 点火模块减震圈衬管 | BUSHING, DAMPER | 3 | | | | |
| 38 | F25-05090004 | 点火模块减震圈 | DAMPER | 3 | | | | |
| 39 | F40-05100800E1 | 燃油冷却器 | COOLER, FUEL | 1 | | | | |
| 40 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 1 | | | | |
| 41 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 4 | | | | |
| 42 | GB/T96-6 | 大垫圈 6 | BIG WASHER 6 | 3 | | | | |
| 43 | F40-05100703E1 | 油杯放油螺钉 | DRAIN BOLT, OIL CUP | 1 | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|---|---|-----------|--|--|--|---------------|
| 1 | F40-05000046E1 | 转接头螺钉 | BOLT, ADAPTER | 1 | | | | |
| 2 | GB/T982-12 | 组合密封垫圈 12 | COMPOUND SEAL WASHER 12 | 2 | | | | |
| 3 | F40-05000045E1 | 共轨转接头 | ADAPTER, COMMON RAIL | 1 | | | | |
| 4 | GB/T70.1-M6x35 | 内六角螺钉 M6x35 | INNER HEXAGON BOLT M6x35 | 3 | | | | |
| 5 | F40-05000044E1 | 共轨垫管 | BUSHING, COMMON RAIL | 3 | | | | |
| 6 | F60-05000024 | 燃油共轨 | COMMON RAIL, FUEL OIL | 1 | | | | |
| 7 | F40-05090300E1 | 燃油喷射器 | FUEL INJECTOR | 4 | | | | |
| 8 | F15-07010004 | 堵塞 1/8 | PLUG SCREW 1/8 | 1 | | | | |
| 9 | S7133-13.3 | 单耳无板卡箍 13.3 | SINGLE LUG CLAMP | 4 | | | | |
| 10 | F40-05000071E1 | 燃油定型管 B | SHAPED TUBE B, FUEL OIL | 1 | | | | |
| 11 | F40-05000040E1 | 燃油过滤器接头 A | JOINT A, FUEL FILTER | 2 | | | | |
| 12 | F40-05091100E1 | 高压燃油过滤器 | FUEL FILTER | 1 | | | | |
| 13 | F25-07150301W | 继电器护套 | RELAY JACKET | 1 | | | | |
| 14 | F60-05000008 | 燃油管 C $\varnothing 6x \varnothing 12.5x780$ (EPA) | FUEL PIPE C $\varnothing 6x \varnothing 12.5x780$ | 1 | | | | |
| 15 | F40-05100511E1 | 油泵放油管 | OIL PIPE, OIL PUMP | 1 | | | | |

Relieve the Fuel Pressure in the Fuel Lines

Before carrying out maintenance and inspection of the fuel system, the fuel pressure in the fuel pipeline shall be released. Avoid accidents caused by high-pressure fuel injection during maintenance.

1. Connect the pressure gauge with the pressure relief pipe to the oil pump check valve of the electric fuel pump;



1. Fuel pump check valve.

2. Insert the pressure relief pipe into a suitable container;
Attention:
Do not release the pressure directly, and the fuel will be discharged while the pressure is released. Fuel spraying can cause accidents and violate local emission regulations.
3. Press the pressure release button to release the pressure until the pressure inside the electric fuel pump is balanced with the outside world.


Remove and Check the Fuel Joint

1. Remove the bolt securing the fuel joint.
2. Remove fuel joint.
3. Check the fuel joint for cracks, leaks or damage.

4. Connect the outlet of the fuel joint to the vacuum manometer.
5. Detect whether the negative pressure can be maintained for more than 10 seconds under the specified pressure. Replace it if necessary.
Specified pressure: 50kPa

Remove and Check the Fuel Pump

1. Remove the bolt securing the fuel pump.
2. Remove the fuel pump.
3. Connect a vacuum manometer to the inlet of the fuel pump.
4. Block the outlet of the oil pump with your fingers and apply the specified positive pressure. Check for air leaks.
Specified pressure: 50kPa
5. Apply a prescribed negative pressure. Check for air leaks.
Specified pressure: 30kPa
6. Connect a vacuum manometer to the outlet of the fuel pump.
7. Block the inlet of the oil pump with your fingers and apply the specified negative pressure. Check for air leaks.
If necessary, disassemble the oil pump and check it.
Specified pressure: 50kPa
8. Remove the 4 bolts and separate the fuel pump cover from the fuel pump seat.
9. Remove the valve plate screw from the fuel pump body and remove the valve plate.
10. Press the plunger and diaphragm, rotate the fuel pump seat and align the notch with the groove on the plunger. Remove needle roller.
11. Check whether there are cracks on the diaphragm, whether the riveting is loose, and whether the valve plate is damaged. Replace it if necessary.



12. Follow steps 8-10 in reverse sequence and assemble the oil pump.


Check the Fuel Filter

Check whether the filter screen of the filter is blocked or there are sundries, and check whether the filter cup is damaged or leaked.

If necessary, clean with gasoline or replace the filter screen.

Note:

Apply lubricating oil to the O-ring before reassembling the filter cup.




- 1 . Filter cup lid
- 2 . Filter screen
- 3 . Float
- 4 . O-ring
- 5 . Filter cup

Remove and Check the Electric Fuel Pump

Disassembly of electric fuel pump

1. Loosen the oil drain screw of the oil cup and drain the fuel in the oil cup into a suitable container.
2. Remove fuel line and cooling water line and disconnect the wiring harness connection.
3. Remove the mounting screws of the electric fuel pump and remove the electric fuel pump from the engine.
4. Disconnect the line connection between the fuel cooler and the electric fuel pump and remove the fuel cooler.
5. Remove the 5 cross-recessed pan-head screws (M4×16) and remove the electric fuel pump body assembly.



6. Pull off the oil pump assembly and disconnect the oil pump connector assembly;
7. Check and clean the oil pump filter screen on the oil pump assembly;
8. Check the rubber sleeve at the oil pump nozzle and replace it if it is aged, damaged or cracked.
9. Loosen the screw fixing the float pin and remove the float;
10. Remove the baffle; (if necessary)
11. Check and clean the oil cup assembly of the electric fuel pump;

12. Loosen the fixing screw of the pressure valve pressure plate and remove the pressure regulating valve;

13. Check the O-ring of the pressure regulating valve; Replace it if necessary;

14. After the check, clean the parts and install the electric fuel pump in the reverse order.

Attention: A new oil cup sealing ring is required; The screws shall be tightened to the specified torque!

Check the Fuel Pipe and Fuel Filter

1. Check the fuel pipe for damage.
2. Check whether the high-pressure fuel filter is cracked and whether the fuel flows smoothly. Replace it if necessary.

Check the Fuel Common Rail

Check the fuel common rail for leaks or cracks and damage, and replace it if necessary.


Engine

Attention:


In order to avoid accidental starting when repairing the engine, adequate protective measures should be taken to disconnect the ignition system. For example:

Remove the engine stop safety cable from the emergency stop switch assembly and remove the spark plug cap from the spark plug.


Decomposition Schematic Diagram




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|--------------------------|-----------|--|--|--|---------------|
| 1 | GB/T5782-M8x35 | 六角螺栓 M8x35 | BOLT M8x35 | 1 | | | | |
| 2 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 11 | | | | |
| 3 | F25-05010106 | 发动机悬挂钩 | POTHOOK, ENGINE | 1 | | | | |
| 4 | F60-05010000 | 机体机座组件 | CRANKCASE ASSY | 1 | | | | |
| 5 | F15-07010004 | 堵塞 1/8 " | JAM 1/8 " | 3 | | | | |
| 6 | F25-00000014 | 定位销 Φ8x12 | DOWEL PIN Φ8x12 | 2 | | | | |
| 7 | F25-05010104 | 堵塞 1/2 " | JAM 1/2 " | 1 | | | | |
| 8 | F25-05010103 | 堵塞 3/4 " | JAM 3/4 " | 1 | | | | |
| 9 | F25-05000035 | 六角螺栓 M8x80 | BOLT M8x80 | 10 | | | | |
| 10 | F15-07000030 | 六角螺栓 M6x35 | BOLT M6x35 | 10 | | | | |
| 11 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 22 | | | | |
| 12 | F40-00000003 | 发动机密封垫 | GASKET, ENGINE | 1 | | | | |
| 13 | F25-05000100 | 机油滤清器 | OIL FILTER | 1 | | | | |
| 14 | F15-07010003 | 机滤螺柱 M20x1.5x35 | STUD SCREW M20x1.5x35 | 1 | | | | |
| 15 | F60-05000004 | 排气盖板密封垫 | GASKET, EXHAUST COVER | 1 | | | | |
| 16 | F60-05000005 | 排气盖板 | COVER, EXHAUST | 1 | | | | |
| 17 | F40-05000038 | 堵塞垫片 | GASKET, JAM | 1 | | | | |
| 18 | F40-05000037 | 堵塞 M18x1.5 | JAM M18x1.5 | 1 | | | | |
| 19 | F25-05010113 | 出水嘴接头 | JOINT, WATER NIPPLE | 1 | | | | |
| 20 | GB/T5782-M6x35 | 六角螺栓 M6x35 | BOLT M6x35 | 12 | | | | |
| 21 | F15-07010021 | 节温器盖板 | COVER, THERMOSTAT | 1 | | | | |
| 22 | F15-07000031 | 节温器 (S60) | THERMOSTAT (S60) | 1 | | | | |
| 23 | F15-07010022 | 节温器垫 | GASKET, THERMOSTAT | 1 | | | | |
| 24 | F40-05000003 | 线卡 | CLAMP | 1 | | | | |
| 25 | F60-05000028 | 水管 B ∅6x ∅11x330 | WATER PIPE B ∅6x ∅11x330 | 1 | | | | |
| 26 | F60-05000047 | 定型水管 | WATER PIPE, SHAPED | 1 | | | | |
| 27 | F40-03000016 | 三通 | THREE WAY | 1 | | | | |
| 28 | F60-05000026 | 水管 A ∅6x ∅11x500 | WATER PIPE A ∅6x ∅11x500 | 1 | | | | |
| 29 | F60-05000030 | 水管 C ∅5x ∅10x250 | WATER PIPE C ∅5x ∅10x250 | 1 | | | | |
| 30 | F60-05000037 | 水管 D ∅5x ∅10x500 | WATER PIPE D ∅5x ∅10x500 | 1 | | | | |
| 31 | F60-05000050 | F型三通 | F-TYPE THREE WAY | 1 | | | | |
| 32 | F60-05000040 | 水管 F ∅6x ∅11x100 | WATER PIPE F ∅6x ∅11x100 | 1 | | | | |
| 33 | F60-05000032 | 定型水管 | WATER PIPE, SHAPED | 1 | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|-----------------------------|-----------|--|--|--|---------------|
| 1 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 1 | | | | |
| 2 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 9 | | | | |
| 3 | F40-05090600EI | 进气温度压力传感器 | SENSOR, INTAKE TEMPERATURE | 1 | | | | |
| 4 | F40-05090601EI | 温度压力传感器 O形圈 | O-RING, TEMPERATURE SENSOR | 1 | | | | |
| 5 | F40-05090500EI | 怠速控制阀 | CONTROL VALVE, IDLE | 1 | | | | |
| 6 | F40-05090503EI | 步进电机 | STEP MOTOR | 1 | | | | |
| 7 | F40-05090503-1EI | 步进电机 O形圈 | O-RING, STEP MOTOR | 1 | | | | |
| 8 | F40-05090501EI | 怠速阀体 | IDLE CONTROL | 1 | | | | |
| 9 | F40-05090502EI | 怠速阀 O型圈 | O-RING, IDLE CONTROL | 1 | | | | |
| 10 | GB/T818-M4x10 | 十字槽盘头螺钉 M4x10 | BOLT M4x10 | 2 | | | | |
| 11 | GB/T97.1-4 | 平垫圈 4 | WASHER 4 | 2 | | | | |
| 12 | GB/T818-M5x14 | 十字槽盘头螺钉 M5x14 | SCREW M5x14 | 2 | | | | |
| 13 | GB/T93-5 | 弹性垫圈 5 | SPRING WASHER 5 | 4 | | | | |
| 14 | GB/T97.1-5 | 平垫圈 5 | WASHER 5 | 4 | | | | |
| 15 | F40-05000026EI | 怠速阀定型管 | IDLE CONTROL PIPE | 1 | | | | |
| 16 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 6 | | | | |
| 17 | F40-05090803EI | 进气消音器密封圈 | SEAL, INTAKE SILENCER | 3 | | | | |
| 18 | F60-05001100 | 进气消音器组件 | INTAKE SILENCER ASSY | 1 | | | | |
| 19 | F40-05090403EI | 节气门密封圈 | SEAL, THROTTLE VALVE | 1 | | | | |
| 20 | F40-05090400EI | 节气门体组件 | THROTTLE VALVE ASSY | 1 | | | | |
| 21 | GB/T818-M5x20 | 十字槽盘头螺钉 M5x20 | BOLT M5x20 | 2 | | | | |
| 22 | HT4.0x300 | 尼龙扎带 4.0x300 | CLAMP 4.0x300 | 2 | | | | |
| 23 | F40-05090408EI | 节气门橡胶套 | RUBBER BOOT, THROTTLE VALVE | 1 | | | | |
| 24 | F60-05000043 | 节气门导管 | CONDUIT, THROTTLE VALVE | 1 | | | | |
| 25 | GB/T5783-M6x16 | 六角螺栓 M6x16 | BOLT M6x16 | 1 | | | | |
| 26 | F60-05000011 | 回气管 A | AIR PIPE A | 1 | | | | |
| 27 | F60-05000048 | 定型回气管 | AIR PIPE | 1 | | | | |
| 28 | GB/T818-M4x16 | 十字槽盘头螺钉 M4x16 | SCREW M4x16 | 2 | | | | |
| 29 | GB/T93-4 | 弹性垫圈 4 | SPRING WASHER 4 | 2 | | | | |
| 30 | GB/T96-4 | 平垫圈 4 | WASHER 4 | 2 | | | | |
| 31 | F40-05090401EI | 节气门位置传感器 | POSITION SENSOR, THROTTLE | 1 | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|------------------------------|-----------|--|--|--|---------------|
| 1 | F15-07050004 | 加油口盖 | FILLER CAP, ENGINE OIL | 1 | | | | |
| 2 | JASO F404 35 025 | 加油口盖 O形圈 | O-RING | 1 | | | | |
| 3 | F60-05030000 | 气缸头罩组件 | COVER ASSY, CYLINDER HEAD | 1 | | | | |
| 4 | F60-05030001 | 气缸头罩 | COVER, CYLINDER HEAD | 1 | | | | |
| 5 | F40-05070002 | 呼吸器接头 | CONNECTOR, BREATHER | 1 | | | | |
| 6 | F25-05010107 | 滤网 | SIEVE NET | 1 | | | | |
| 7 | F60-05030002 | 呼吸器盖板 | PLATE, BREATHER | 1 | | | | |
| 8 | GB/T818-M4x10 | 十字槽盘头螺钉 M4x10 | SCREW M4x10 | 4 | | | | |
| 9 | F60-05000003 | 气缸头罩密封圈 | SEAL, CYLINDER HEAD | 1 | | | | |
| 10 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 7 | | | | |
| 11 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 11 | | | | |
| 12 | F25-05050021 | 凸轮轴油封 37x50x7 R | OIL SEAL, CAMSHAFT | 1 | | | | |
| 13 | F15-07010005 | 堵塞 1/4" | PLUG 1/4" | 8 | | | | |
| 14 | F25-05050007 | 凸轮轴限位螺栓垫片 | WASHER, LIMITING BOLT | 1 | | | | |
| 15 | F25-05050006 | 凸轮轴限位螺栓 | LIMITING BOLT, CAMSHAFT | 1 | | | | |
| 16 | F25-05000003 | 平垫圈 9 | WASHER 9 | 10 | | | | |
| 17 | F25-05000002 | 六角凸缘螺栓 M9x1.25 | BOLT M9x1.25 | 10 | | | | |
| 18 | F60-05020100 | 气缸头组件 | CYLINDER HEAD ASSY | 1 | | | | |
| 19 | F20-05000037 | 火花塞 DPR7EA-9 | SPARK PLUG DPR7EA-9 | 4 | | | | |
| 20 | F8-05000022 | 六角螺栓 M6x25 | BOLT M6x25 | 5 | | | | |
| 21 | F25-00000014 | 定位销 \varnothing 8x12 | DOWEL PIN \varnothing 8x12 | 2 | | | | |
| 22 | F60-05000100 | 气缸垫组件 | GASKET ASSY, CYLINDER HEAD | 1 | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|--------------------------------|-----------|--|--|--|--|---------------|
| 1 | F25-05050002 | 排气门 | VALVE, EXHAUST | 4 | | | | | |
| 2 | F25-05050003 | 气门弹簧垫圈 | WASHER, VALVE SPRING | 8 | | | | | |
| 3 | PS2700. 04. 03 | 气门油封 | SEAL, VALVE STEM | 8 | | | | | |
| 4 | F25-05050005 | 气门弹簧 | SPRING, VALVE | 8 | | | | | |
| 5 | F15-07040006 | 气门弹簧座圈 | RETAINER, VALVE SPRING | 8 | | | | | |
| 6 | F15-07040007 | 气门弹簧卡圈 | COTTER, VALVE SPRING | 16 | | | | | |
| 7 | F25-05050300 | 摇臂组件 | ROCKER ASSY | 8 | | | | | |
| 8 | F25-05050301 | 摇臂 | ROCKER | 8 | | | | | |
| 9 | F15-07040303 | 调整螺钉 | SCREW, VALVE ADJUSTING | 8 | | | | | |
| 10 | F15-07040304 | 锁紧螺母 | LOCK NUT | 8 | | | | | |
| 11 | F25-05050001 | 进气门 | VALVE, INTAKE | 4 | | | | | |
| 12 | F60-05020001 | 摇臂轴 | SHAFT, ROCKER | 1 | | | | | |
| 13 | F25-05050009 | 摇臂轴固定板A | FIXED PLATE A, ROCKER SHAFT | 2 | | | | | |
| 14 | F25-05050019 | 摇臂轴六角法兰螺栓 | FLANGE BOLT, ROCKER SHAFT | 5 | | | | | |
| 15 | F40-05040002 | 弹簧板托板 | SUPPORTING PLATE, SPRING PLATE | 2 | | | | | |
| 16 | F25-05050011 | 摇臂限位弹簧板 | SPRING PLATE, ROCKER | 2 | | | | | |
| 17 | F25-05050012 | 摇臂轴固定板B | SPRING PLATE B, ROCKER | 2 | | | | | |
| 18 | F40-05040003 | 摇臂轴固定板B | FIXED PLATE B, ROCKER SHAFT | 1 | | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|--|-------------------------------|-----------|--|--|--|--|---------------|
| 1 | F25-05020003 | 曲轴油封 B \varnothing 43x \varnothing 54.8x6 R | OIL SEAL B | 1 | | | | | |
| 2 | F60-05000001 | 曲轴 | CRANKSHAFT | 1 | | | | | |
| 3 | F25-05010302-1 | 曲轴轴瓦 (黑色) | BEARING SHELL, CRANKSHAFT | 10 | | | | | BLACK |
| | F25-05010302-2 | 曲轴轴瓦 (棕色) | BEARING SHELL, CRANKSHAFT | | | | | | BROWN |
| 4 | F25-05020002 | 曲轴油封 A \varnothing 35x \varnothing 46.85x6 L | OIL SEAL A | 1 | | | | | |
| 5 | F25-05020200 | 连杆组件 | CONNECTING ROD ASSY | 4 | | | | | |
| 6 | F25-05020204 | 连杆螺栓 | BOLT, CONNECTING ROD | 8 | | | | | |
| 7 | F25-05020203-1 | 连杆轴瓦 (黑色) | BEARING SHELL, CONNECTING ROD | 8 | | | | | BLACK |
| | F25-05020203-2 | 连杆轴瓦 (棕色) | BEARING SHELL, CONNECTING ROD | | | | | | BROWN |
| 8 | F25-05020106 | 活塞销挡圈 | CIRCLIP, PISTON PIN | 8 | | | | | |
| 9 | F25-05020105 | 活塞销 | PIN, PISTON | 4 | | | | | |
| 10 | F40-05020100 | 活塞组件 | PISTON ASSY | 4 | | | | | |
| 11 | F40-05020101 | 活塞 | PISTON | 4 | | | | | |
| 12 | F25-05020102 | 活塞环组件 | PISTON RING ASSY | 4 | | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|-----------------------|-------------------------|---------------------------|-----------|--|--|--|--|---------------|
| 1 | F40-05000007 | 正时带轮螺母 | NUT, TIMING PULLEY | 1 | | | | | |
| 2 | F25-05000021 | 正时带轮 | TIMING PULLEY | 1 | | | | | |
| 3 | F25-05000023 | 正时皮带 | TIMING BELT | 1 | | | | | |
| 4 | F40-05000008 | 正时带轮盖板 | PLATE, TIMING BELT | 1 | | | | | |
| 5 | F4-04000019 | 半圆键 4x5. 3x13 | WOODRUFF KEY | 1 | | | | | |
| 6 | GB/T5785-M10x1. 25x40 | 六角螺栓 M10x1. 25x40 | BOLT M10x1. 25x40 | 1 | | | | | |
| 7 | GB/T97. 1-10 | 平垫圈 10 | WASHER 10 | 1 | | | | | |
| 8 | F25-05050018 | 从动轮垫圈 | WASHER, DRIVEN PULLEY | 1 | | | | | |
| 9 | F40-05040006 | 从动轮 | DRIVEN PULLEY | 1 | | | | | |
| 10 | F25-05050016 | 从动轮定位销 | DOWEL PIN, DRIVEN PULLEY | 1 | | | | | |
| 11 | F60-05020200 | 凸轮轴组件 | CAMSHAFT ASSY | 1 | | | | | |
| 12 | F40-05040407 | 机油泵密封垫 | GASKET, OIL PUMP | 1 | | | | | |
| 13 | F40-05040400 | 机油泵组件 | OIL PUMP ASSY | 1 | | | | | |
| 14 | F40-05040401 | 机油泵体 | BODY, OIL PUMP | 1 | | | | | |
| 15 | F40-05040405 | 机油泵密封圈 | SEAL, OIL PUMP | 1 | | | | | |
| 16 | F40-05040404 | 油泵转子轴 | ROTOR SHAFT , OIL PUMP | 1 | | | | | |
| 17 | GB/T309- ∅4x15. 8 | 滚针 ∅4x15. 8 | NEEDLE ROLLER ∅4x15. 8 | 1 | | | | | |
| 18 | F40-05040403 | 油泵内转子 | INNER ROTOR , OIL PUMP | 1 | | | | | |
| 19 | F40-05040402 | 油泵外转子 | OUTER ROTOR , OIL PUMP | 1 | | | | | |
| 20 | F15-07110003 | 溢流阀柱塞 | PLUNGER, OIL RELIEF VALVE | 1 | | | | | |
| 21 | F40-05040408 | 溢流阀弹簧 | SPRING, OIL RELIEF VALVE | 1 | | | | | |
| 22 | F40-05040406 | 机油泵盖 | COVER, OIL PUMP | 1 | | | | | |
| 23 | GB/T823-M6x16 | 十字槽小盘头螺钉 M6x16 | SCREW M6x16 | 2 | | | | | |
| 24 | GB/T97. 1-6 | 平垫圈 6 | WASHER 6 | 4 | | | | | |
| 25 | GB/T5782-M6x40 | 六角螺栓 M6x40 | BOLT M6x40 | 4 | | | | | |

Special Tools




Piston slideway



Flywheel gripper
and flywheel puller



Valve spring compressor kit



Clearance gauge



Oil filter spanner

Check the Compression Pressure

1. Start the engine, warm it up for 5 minutes, then shut it down.
2. Remove engine stop safety line.
3. Remove the spark plug and connect the pressure gauge to the spark plug hole.

Attention:

Before removing the spark plug, clean the pit where the spark plug is installed with compressed air to prevent dust or other sundries from entering the cylinder.

4. Fully open the throttle, turn the crankshaft with the starter or starting motor, and check the cylinder pressure when the reading on the pressure gauge is stable.

Note:

For models using the control box, remove the throttle linkage, fully open the carburetor throttle lever by hand, and then detect the pressure.

5. If the pressure is lower than the specified value or there is a difference between the cylinders, add a small amount of oil to the cylinders and then carry out the detection.

Compression pressure: 840 kPa

Note:

If the cylinder pressure continues to increase, check the piston and piston ring for damage. Replace it if necessary.

If the cylinder pressure does not increase, check the valve clearance, valve, valve seat, cylinder liner, cylinder head and cylinder head gasket.

Adjust or replace it if necessary.

The outboard motor is equipped with automatic pressure relief device, and the data cannot be very accurate.

Check the Oil Pressure

1. Start the engine, warm it up for 5 minutes, then shut it down.
2. Remove oil pressure switch and connect pressure gauge.


Note:

Use a manometer with a 1/8 pitch thread adapter.

3. Check oil pressure
Oil pressure (reference data): 100kpa (800±50 r/min)

Disassemble the Engine

1. Open the top cover.
2. Remove the flywheel cover.
3. Remove the throttle cable.
4. Remove the carburetor.
5. Remove the flywheel with special tools.



Flywheel gripper and flywheel puller

6. Remove the semicircle key.
7. Disconnect the engine stop switch line and the ground wire.
8. Remove the cable joint.
9. Remove the magneto coil.
10. Disconnect the wires of electrical components such as storage battery, starting motor, starting relay, tilting relay and control box connector, Disconnect the ground wire and the water pipe.
11. Remove the ignition coil, ECU device, ignition coil and spark plug.
12. Remove the bolts connecting the engine to the water unit.
13. Lift the engine and remove the locating pin.

Pulley and Timing Belt

1. Turn the flywheel clockwise. Align "1" on the driven pulley with "▼" on the cylinder head.

Attention:

Do not turn the flywheel counterclockwise, otherwise the valve system will be damaged.

2. Remove timing belt from the driven pulley side.

Attention:

When the timing belt is not installed, do not turn the pulley, otherwise the valve system will be damaged.

3. Remove the driven pulley bolt, remove the driven pulley and the semicircular key.

Note:

Remove the driven pulley bolt with the flywheel gripper.

Do not turn the camshafts when loosening the timing pulley.

4. Remove the timing pulley washer, timing pulley and semicircular key.
5. Check the pulley and timing belt for cracks, damage or wear. Replace it if necessary.
6. Install the semicircular key and the driven pulley.
Align "1" on the driven pulley with "▼" on the cylinder head. Then temporarily tighten the driven pulley bolts.

Attention:

When the timing belt is not installed, do not turn the pulley, otherwise the valve system will be damaged.

7. Install the semicircular key and timing pulley.
Align the notch mark on the timing pulley with the mark "▼" on the body.
8. Install the new timing belt with the part number of the timing belt upright.
Attention:
Do not twist, rotate or bend the timing belt, otherwise the timing belt will be damaged.
Do not put oil or lubricating oil on the timing belt.
Do not turn the pulley counterclockwise, otherwise the valve system will be damaged.
9. Install the timing pulley cover plate and temporarily tighten the timing pulley nut.
10. Turn the timing pulley clockwise for 2 turns to eliminate the slackness of the timing belt.
Check if the alignment marks are aligned.
11. Tighten the bolts and nuts.
Locking torque: Driven pulley bolt 38 Nm
Note:
Remove the driven pulley bolt with the flywheel gripper.
Tighten timing pulley nuts with a special socket wrench for timing pulley nuts.

Disassembling and Check

Cylinder Head

Disassembling

1. Remove cylinder head cover bolts.
2. Remove the cylinder head bolts in reverse order according to the numeric markings on the cylinder head.
3. Remove the cylinder head and then remove the oil pump.
4. Remove the rocker shaft, spring and rocker assembly.

Note:

Before removing the rocker shaft, loosen the lock nut and adjust the screw to the relaxed state.

5. Remove intake and exhaust valves using the valve spring compressor.



Valves and valve guides


1. Check the width of the valve sealing surface if it is not within the specified scope. Trim the valve seat ring.

Width of sealing surface:

| | |
|---------------|--------------|
| Intake valve | 1.84~2.97 mm |
| Exhaust valve | 1.98~3.11 mm |

2. Check the valve edge thickness T; If the specified value is not met, replace the valve.
Valve edge thickness:

| | |
|---------------|------------|
| Intake valve | 0.6~1.0 mm |
| Exhaust valve | 0.7~1.1 mm |




3. Check valve stem diameter. If it is not within the specified scope. Replace the valve.
Valve stem diameter:

| | |
|---------------|--------------|
| Intake valve | 5.48~5.49 mm |
| Exhaust valve | 5.46~5.47 mm |

4. Check the roundness of the valve stem. If it exceeds the limit, replace the valve.
Valve stem roundness limit 0.03mm

5. Check the inner diameter of the valve guide.
Inner diameter of the valve guide. 5.50~5.51 mm



Attention:

When replacing valve, be sure to use new valve guides and valve seal.

Valve spring

1. Check the free length of the valve spring; If it is less than the specified value, replace it.
Free length: 39.85 mm
Min. free length: 37.85 mm
2. Check the inclination of the valve spring; If it exceeds the limit, replace the valve.
Inclination limit: 1.7 mm

Valve rocker and rocker shaft


1. Check the contact surface of the valve rocker and rocker shaft for wear. Replace it if necessary.
2. Measure whether the inner diameter of the valve rocker and the outer diameter of the rocker shaft conform to the specified values. Replace it if necessary.
Inner diameter of the valve rocker: 16.000~16.01 mm
Outer diameter of rocker shaft: 15.97~15.99 mm

Camshaft

1. Check cam size.
Replace the camshaft if necessary.

| | | |
|-------------------------|---------|----------------|
| Height of cam | Intake | 30.89~30.99 mm |
| | Exhaust | 30.82~30.92 mm |
| Diameter of base circle | | 25.95~26.05 mm |

2. Check camshaft roundness. Replace it if necessary.
Roundness limit: 0.03mm



3. Check camshaft journal diameter and cylinder head shaft hole inner diameter. Replace it if necessary.
 Camshaft journal top diameter a1 (driven pulley mounting end): 36.93~36.94 mm
 Camshaft journal centre and rear diameter a2: 36.94~36.95 mm
 Cylinder head shaft hole inner diameter b: 37.00~37.02 mm


4. Calculate camshaft oil clearance c ($c=b-a$), If the specified value is not met, replace it.
 Top of camshaft: 0.06~0.10 mm
 Centre and rear of camshaft: 0.05~0.09 mm

Attention:

The camshaft and cylinder head need to be replaced together.

Check the oil pump

1. Remove the screws securing the oil pump and remove the oil pump.
2. Open the oil pump cover and check the oil pump rotor clearance as shown. If the specified value is not met, replace it.



| | |
|---|--------------|
| Clearance between outer rotor and casing a | 0.09~0.15 mm |
| Clearance between outer rotor and inner rotor b | 0.01~0.10 mm |
| Clearance between rotor and cover c | 0.03~0.08 mm |

Joint surface of cylinder head and body

1. Remove carbon deposits from the combustion chamber and check for damage.
2. Use a ruler and gap gauge to check the bending of the joint surface. If the specified value is not met, replace it.
 Cylinder head bending limit: 0.03 mm

Replace valve guide

1. Knock off the valve guide from the direction of the combustion chamber.
2. Knock in a new valve guide from the top surface of the cylinder head.

Note:

Apply oil to the surface of the guide before installation.

3. Hinge the inner diameter of the conduit to the specified value with a reamer.
 Inner diameter of the valve guide: 5.50~5.51 mm

Note:

Do not rotate the reamer counterclockwise when taking it out.

Check the valve seat ring.

1. Remove carbon deposits from the valve.
2. Apply a thin layer of dye evenly to the sealing surface of the valve seat ring.
3. Grind the valve on the valve seat with a valve grinding tool.
4. Measure the width of the valve sealing surface.
 Dye will stick to the valve sealing surface.

If the valve and valve seat ring are not properly matched or the width of the sealing surface does not conform to the specified value, trim the valve seat.

If the contact is uneven, replace the valve guide.


Width of inlet and exhaust valve sealing surface: 0.9~1.1mm

Trim the valve seat ring


1. Trim the valve with a 45° valve seat ring cutter and adjust the width of the sealing surface.

Turn the cutter clockwise until the surface of the seat ring is smooth.


2. If the valve sealing surface is too wide and in the middle of the valve surface, trim the top edge of the seat ring with a 30° cutter and the bottom edge of the seat ring with a 60° cutter and adjust the width of the sealing surface.



3. If the valve sealing surface is too narrow and at the top edge of the valve surface, trim the top edge of the seat ring with a 30° cutter, if so, adjust the width of the sealing surface with a 45° cutter.



4. If the valve sealing surface is too narrow and at the bottom edge of the valve surface, trim the bottom edge of the seat ring with a 60° cutter, and if so, adjust the width of the sealing surface with a 45° cutter.



5. Apply a thin layer of abrasive evenly on the valve seat ring and grind the valve with a valve grinding tool.

6. Remove the residual abrasive.

7. Check the valve sealing surface width again.

Attention:

Don't cut the valve too much, turn the cutter evenly with a downward force of 40 ~ 50N.

Do not attach the abrasive to the valve stem and valve guide.

Install valve

1. Install a new valve oil seal and coat the valve guide with engine oil.
2. Install the valve, valve spring pad, valve spring and spring seat in sequence.
3. Compress the valve spring with a valve spring compressor and install the valve spring retainer.
4. Tap the valve spring seat lightly with a plastic or rubber hammer to secure the retainer.

Assemble cylinder head

1. Install the new oil seal with special tools.
2. Fit the camshaft into the cylinder head from the direction of the oil pump.
3. Check that the camshaft head locating pin hole is positioned in the direction of the cylinder head cover (rocker side). If necessary, make adjustments.
4. Install the rocker assembly, spring and rocker shaft.
5. Assemble the oil pump.


Note:

Ensure that the mark on the outer rotor face the oil pump cover

6. Fit oil pump by aligning oil pump drive shaft and camshaft pin.

Attention:

Before installing the oil pump, make sure that the oil circuit is smooth and fill the oil pump with oil.



Crankcase Disassembling

1. Remove the oil filter with special tools.

Note:

Put a cloth under the oil filter.



Filter wrench

2. Remove the bolts in reverse order according to the serial number on the edge of the screw hole on the exhaust cover plate.
3. Remove thermostat cover, exhaust cover, gasket and locating pin.
Clean the anode surface, check the anode, and replace the anode if the corrosion exceeds half of the surface.
Check the exhaust cover plate for cracks, deformation or corrosion. Replace it if necessary.
4. Remove the box bolts in reverse order according to the serial number on the edge of the screw hole of the engine base, and remove the engine base.

5. Remove the connecting rod bolt and connecting rod cover, remove the crankshaft, and then remove the connecting rod and piston assembly.

6. Remove the piston pin circlip with pliers, then remove the piston pin and the piston.

7. Remove the oil seal, locating pin and bearing bush.

Piston

1. Measure the piston outer diameter at the specified measuring point.

If the specified value is not met, replace it.


Diameter of piston: 64.950~64.965 mm

Measuring point $\text{\textcircled{a}}$: 5mm

2. Check the inner diameter of piston pin bore.

If the specified value is not met, replace it.

Inner diameter of piston pin bore: 15.974~15.985mm



Cylinder bore

1. Measure the piston outer diameter $\text{\textcircled{1}}$, $\text{\textcircled{2}}$ and $\text{\textcircled{3}}$ at the specified measuring point.


At each measure point, six diameters parallel to the crankshaft direction D1, D3, D5 and perpendicular to the crankshaft direction D2, D4, D6 are measure respectively.

Height of measuring point $\text{\textcircled{1}}$ 20 mm;

$\text{\textcircled{2}}$ 60 mm;

$\text{\textcircled{3}}$ 100 mm

Cylinder bore: 65.000~65.013 mm



2. Calculate the taper limit and roundness limit. If the specified value is exceeded, replace the crankcase.

taper limit: 0.08 mm (D1-D5, D2-D6)

Roundness limit: 0.05 mm (D2-D1, D6-D5)

Piston pin outer diameter

Check the piston pin outer diameter; If it does not conform to the specified value, replace it.

Piston pin outer diameter: 15.965~15.970 mm

Piston ring

1. Check the piston ring cross-sectional dimensions. If the specified value is not met, replace it.

| | Thickness | Section width |
|----------------------|--------------|---------------|
| Top ring | 1.17~1.19 mm | 2.39~2.41 mm |
| 2 nd ring | 1.47~1.49mm | 2.49~2.51 mm |
| Oil ring | 2.34~2.46 mm | 2.75mm |

2. Push the piston ring parallel into the cylinder with the piston to the specified measuring point (20mm from the joint surface).

3. Measure the end clearance of piston ring with clearance gauge; If it does not conform to the specified value, replace it.

End clearance (when installing) Top ring 0.15 ~ 0.30 mm

2nd ring 0.30~0.50 mm

Oil ring 0.20 ~ 0.70 mm

- Install the piston ring on the piston and measure the clearance between the piston ring and the piston ring groove with clearance gauge. If it does not conform to the specified value, replace it.

Specified clearance: Top ring 0.02 ~ 0.06 mm
 2nd ring 0.02~0.06 mm
 Oil ring 0.04 ~ 0.18 mm

Inner diameter of connecting rod small end


Measure the inner diameter of small end. If the specified value is not met, replace it.

Inner diameter of small end: 15.985~15.998 mm

Connecting rod big-end backlash


Measure big-end backlash. If the specified value is not met, replace the connecting rod or crankshaft or both.

Big-end backlash: 0.05~0.22 mm



Check the connecting rod bolts

- Check the thread diameter of the connecting rod bolt at the position shown.



- Calculate the difference between the diameters of the two threads; If it does not conform to the specified value, replace it.


Diameter difference of connecting rod bolt threads: 0~0.1 mm

Crankshaft

- Measure the crankshaft journal diameter, crank pin diameter and crank pin width. If the specified value is not met, replace the crankshaft.

| | |
|-----------------------------|------------------|
| Crankshaft journal diameter | 42.984~43.000 mm |
| Crank pin diameter | 32.984~33.000 mm |
| Crank pin width | 21.000~21.070mm |

- Check crankshaft runout; If the specified value is exceeded, replace it.



Crankshaft runout limit: 0.04mm

Clearance between crank pin and oil

- Place a plastic clearance gauge on the crank pin and make it parallel to the crankshaft.
- Fit the connecting rod and bearing bush on the crank pin.
- Tighten the connecting rod bolts according to the specified torque.

Locking torque: First time 6 Nm

Second time 17 Nm

4. Remove the connecting rod and measure the width of the plastic clearance gauge after being compressed. If the specified value is exceeded, replace the connecting rod bearing bush.

Oil clearance: 0.020~0.052mm

Note:

Do not turn the connecting rod until the measurement is completed.

Clearance between main journal and oil

1. Clean the mounting surface of bearing bush, main journal, motor body and engine base.
2. Install the bearing bush and crankshaft to the body.
3. Place a plastic clearance gauge on the main journal and make it parallel to the crankshaft.

Note:

Do not place the plastic clearance gauge on the oil hole of the main journal.

4. Install the bearing bush on the engine base and install the engine base on the body.
5. Tighten the bolts with the specified torque in the order of the numeric marks on the engine base.

Locking torque:

| | | |
|----------------------------|----|-------|
| 1 st tightening | M8 | 15 Nm |
| 2 nd tightening | | 30 Nm |
| 1 st tightening | M6 | 6 Nm |
| 2 nd tightening | | 12 Nm |

6. Remove the engine base and measure the width of each plastic clearance gauge after being compressed. If the specified value is exceeded, replace the bearing bush.

Oil clearance: 0.012~0.044mm

Note:

Do not turn the crankshaft until the measurement is completed.

Engine body and base

1. Check the engine body and base for cracking, damage and corrosion; If any, replace it.
2. Check the cooling water channel for dirt or blockage; If any, clean it.

Reinstall

Assemble Piston Connecting Rod

Install the piston, connecting rod, piston pin and piston pin clip clutch.

Note:

When installing, make sure that the mark on the connecting rod is on the same side as that on the top of the piston.

Install Piston Ring


1. Install the piston ring in the order of oil ring, second ring and top ring.

Note:

When installing the second ring, make sure that the mark faces the top of the piston.

2. Position of the piston ring notch.

- Oil ring lower retainer 1
- Oil ring elastic ring 2
- Oil ring upper retainer 3
- Second ring 4
- Top ring 5



Install Piston

Install the piston using the piston slide rail, Ensure that the "UP" sign on the top of the piston faces the flywheel.

Note:

When installing, apply oil to the sides of the piston and piston ring.



Install Crankshaft

1. Install the bearing bush to the body.

Note:

Insert the raised part on the bearing bush into the groove of the corresponding part of the body.

2. Install the crankshaft to the body and install the oil seal.

Note:

Apply oil to the inner side of the oil seal before installation.

3. Install the connecting rod cover to the connecting rod and tighten the bolts to the specified torque in two steps.

Locking torque: First time 6 Nm
Second time 17 Nm

Note:

Align the connecting rod cover with the mark on the connecting rod.
Apply oil to the connecting rod bolts before installation.

Assemble the Engine

1. Apply sealant to the joint surface of the base, and install the positioning pin and the base. Tighten the bolts twice according to the order marked on the base.

Locking torque:

| | | |
|----------------------------|----|-------|
| 1 st tightening | M8 | 15 Nm |
| 2 nd tightening | | 30 Nm |
| 1 st tightening | M6 | 6 Nm |
| 2 nd tightening | | 12 Nm |

Note:

Apply oil to the moving surface before installation.

Apply oil to the bolts before installation.

2. Install oil filter using special tools and tighten it to the specified torque.
Locking torque: 18 Nm

Note:

Before installation, inject oil into the oil channel.

3. Install the exhaust cover, thermostat and thermostat cover.

Tighten them at the specified torque twice in the order indicated on the exhaust cover plate.

Locking torque: First time 6 Nm

First time 12 Nm

6. Install the locating pin, cylinder gasket and cylinder head assembly.
7. Check the keyway position of semicircular key on camshaft
8. Tighten the cylinder head bolts to the specified values in 2 steps according to the sequence marked on the cylinder head.

Specified torque:

| | | |
|----------------------------|----|-------|
| 1 st tightening | M9 | 23 Nm |
| 2 nd tightening | | 46 Nm |
| 1 st tightening | M6 | 6 Nm |
| 2 nd tightening | | 12 Nm |

Attention:

Do not use old cylinder gaskets.

9. Install the timing pulley, driven pulley, timing belt and breather pipe.

Attention:

When installing the timing belt, ensure that the mark on the driven pulley is aligned with the "▼" on the cylinder head; Ensure that the mark on the timing pulley is aligned with the "▼" on the body.

10. Adjust valve clearance.


11. Install the cylinder head cover and tighten the bolts in the order indicated on the cylinder head cover.

12. Install electrical system components in reverse order according to the removal sequence

13. Connect the wire of the electrical system.

14. Install the fuel system.

Upper Casing
Top Cowling
Decomposition Schematic Diagram




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|------------------------------|-----------|--|--|--|--|---------------|
| 1 | F60-07000000 | 顶罩组件 | TOP COWLING ASSY | 1 | | | | | |
| 2 | F60-07000003 | 顶罩盖 | COVER, TOP COWLING | 1 | | | | | |
| 3 | F40-08000002 | 顶罩 标贴 (右) | STICKER (RIGHT), TOP COWLING | 1 | | | | | |
| 4 | F60-07000001 | 顶罩 | TOP COWLING | 1 | | | | | |
| 5 | F60-08000005 | 顶罩标贴 (前) | STICKER (FRONT), TOP COWLING | 1 | | | | | |
| 6 | F25-06000006 | 扁头螺栓 B | FLAT BOLT B | 2 | | | | | |
| 7 | F60-07000002 | 顶罩 密封橡胶条 | RUBBER SEAL, TOP COWLING | 1 | | | | | |
| 8 | F25-06000004 | 前挂钩 | POTHOOK (FRONT) | 1 | | | | | |
| 9 | GB/T889. 1-6 | I 型非金属嵌件六角锁紧螺母 | M6 LOCKNUT M6 | 4 | | | | | |
| 10 | F25-06000100 | 后挂钩组件 | POTHOOK ASSY (BACK) | 1 | | | | | |
| 11 | F60-07000004 | 后挂钩垫块 | CUSHION, BACK POTHOOK | 1 | | | | | |
| 12 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 4 | | | | | |
| 13 | GB/T97. 1-6 | 平垫圈 6 | WASHER 6 | 4 | | | | | |
| 14 | F40-08000001 | 顶罩标贴 (左) | STICKER (LEFT), TOP COWLING | 1 | | | | | |
| 15 | F40-06000007 | 扁头螺栓 A | FLAT BOLT A | 2 | | | | | |
| 16 | F40-08000003 | 顶罩标贴 (后) | STICKER (BACK), TOP COWLING | 1 | | | | | |


Disassembling and Check

1. Remove sealing rubber strip.
2. Remove the top cover screws.
3. Remove top cover.
4. Remove the locking hook and hook.
5. Check the top cover for cracks, damage or wear. Replace it if necessary.
6. Check the sealing rubber strip for cracks or damage. Replace it if necessary.
7. Check the top cover silencer for cracks or damage. Replace it if necessary.
8. Check the locking hook and hook for cracks, deformation or damage. Replace it if necessary.

Bottom Cowling Decomposition Schematic Diagram



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|------------------------------|--------------------------------|-----------|--|--|--|--|---------------|
| 1 | F60-03000001 | 底罩 | BOTTOM COWLING | 1 | | | | | |
| 2 | F60-03000006FW | 异形橡胶闷头 | RUBBER PLUG, ABNORMAL | 1 | | | | | |
| 3 | F4-05000200 | 燃油管接头组件 | FUEL CONNECTOR ASSY | 1 | | | | | |
| 4 | GB/T6170-M6 | 六角螺母 M6 | NUT M6 | 3 | | | | | |
| 5 | F60-03000005FW | 橡胶挡板 | BAFFLE BOARD, RUBBER | 1 | | | | | |
| 6 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 10 | | | | | |
| 7 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 1 | | | | | |
| 8 | F60-03000003 | 底罩小盖板 | COVER BOARD, BOTTOM COWLING | 1 | | | | | |
| 9 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 4 | | | | | |
| 10 | F25-03000023W | 堵塞支架 | BRACKET, JAM | 1 | | | | | |
| 11 | GB/T845-ST5.5x19 | 十字槽盘头自攻螺钉 ST5.5x19 | SCREW ST5.5x19 | 2 | | | | | |
| 12 | F25-03000100W | 水管堵塞组件 | JAM ASSY | 1 | | | | | |
| 13 | F25-03000101W | 堵塞本体 | JAM | 1 | | | | | |
| 14 | F25-03000102W | 堵塞橡胶圈 | RUBBER RING, JAM | 1 | | | | | |
| 15 | F25-03000103W | 堵塞接头 | JOINT, JAM | 1 | | | | | |
| 16 | F25-03000104W | 堵塞螺母 | NUT, JAM | 1 | | | | | |
| 17 | GB/T5783-M6x14 | 六角螺栓 M6x14 | BOLT M6x14 | 1 | | | | | |
| 18 | F60-03000300 | 钢索固定架组件 | FIXED FRAME ASSY, TIGHTWIRE | 1 | | | | | |
| 19 | F60-03000301 | 钢索固定架 | FIXED FRAME, TIGHTWIRE | 1 | | | | | |
| 20 | F20-03000202W | 推拉索锁夹 | CLAMP | 1 | | | | | |
| 21 | GB/T879.2-3x12 | 轻型直槽弹性圆柱销 $\varnothing 3x12$ | PIN $\varnothing 3x12$ | 1 | | | | | |
| 22 | GB/T5783-M6x30 | 六角螺栓 M6x30 | BOLT M6x30 | 6 | | | | | |
| 23 | F60-03000008 | 波纹橡胶套 | SHEATH, WAVE | 1 | | | | | |
| 24 | GB/T823-M6x12 | 十字槽小盘头螺钉 M6x12 | SCREW M6x12 | 1 | | | | | |
| 25 | F40-03000300E1 | 指示灯组件 | PILOT LAMP ASSY | 1 | | | | | |
| 26 | F20-03000101 | 指示灯密封件 | SEAL, PILOT LAMP | 1 | | | | | |
| 27 | GB/T93-6 | 弹簧垫圈 6 | SPRING-WASHER 6 | 6 | | | | | |
| 28 | F25-00000004 | 特大垫圈 6 | BIG WASHER 6 | 4 | | | | | |
| 29 | F25-03000006 | 减震圈 | DAMPER | 4 | | | | | |
| 30 | F25-03000007 | 减震圈垫管 | BUSHING, DAMPER | 4 | | | | | |
| 31 | F25-03000019 | 拉簧支架组件 | BRACKET ASSY, TENSIONAL SPRING | 1 | | | | | |
| 32 | F15-05000026 | 锁紧块拉簧 | SPRING, TENSION | 1 | | | | | |
| 33 | GB/T5783-M6x12 | 六角螺栓 M6x12 | BOLT M6x12 | 1 | | | | | |
| 34 | F25-03020000 | 顶罩锁紧块组件 | LOCKING ASSY, TOP COWLING | 1 | | | | | |
| 35 | F15-05000036 | 顶罩锁紧手柄尼龙套 B | BUSHING B | 1 | | | | | |
| 36 | F15-05000022 | 顶罩锁紧手柄尼龙套 A | BUSHING A | 1 | | | | | |
| 37 | F15-05000023 | 波形垫圈 | WASHER, WAVE | 1 | | | | | |
| 38 | F60-03000100 | 顶罩锁紧手柄组件 | LOCKING ASSY, TOP COWLING | 1 | | | | | |
| 39 | F15-05000009 | 塑料出水嘴 | WATER NIPPLE, PLASTIC | 1 | | | | | |
| 40 | F40-03000600W | 起翘开关组件 | SWITCH ASSY, TILT | 1 | | | | | |
| 41 | F40-03000008 | 起翘开关护套 | JACKET, TILT SWITCH | 1 | | | | | |
| 42 | T85-03000004 | 电源线护套 | JACKET, BATTERY LINE | 1 | | | | | |
| 43 | F25-03000022W | 水管波纹护套 | JACKET, WAVE | 1 | | | | | |
| 44 | F25-03000002 | 底罩密封条 | SEAL, BOTTOM COWLING | 1 | | | | | |
| 45 | F60-00000014 | 水上装置罩壳 | SHIELD, UPPER CASING | 1 | | | | | |
| 46 | GB/T818-M6x25 | 十字槽盘头螺钉 M6x25 | SCREW M6x25 | 2 | | | | | |
| 47 | F60-03000005BW | 橡胶挡板 | BAFFLE BOARD, RUBBER | 1 | | | | | BEL-D/BEL-T |
| 48 | F60-03000006BW | 异形橡胶闷头 | RUBBER PLUG, ABNORMAL | 1 | | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|-----------------------------------|-------------------------------|----------------------------------|-----------|--|--|--|---------------|
| 1 | F25-0700005W | 操控钢索接头A | TIE-IN A, CONTROL CABLE | 2 | | | | |
| 2 | F15-0000012 | 夹簧 $\varnothing 1.8$ | COLLET $\varnothing 1.8$ | 3 | | | | |
| 3 | F60-05000012 | 油门执行器主动滑轮 | PULLEY DRIVE | 1 | | | | |
| 4 | F60-05000014-2 | 油门执行器螺钉B | BOLT B, PULLEY DRIVE | 1 | | | | |
| 5 | F15-0000009 | 波形垫圈 | WAVE WASHER | 2 | | | | |
| 6 | F60-05000015 | 油门执行器垫圈 | WASHER, PULLEY DRIVE | 2 | | | | |
| 7 | F60-05000013 | 油门执行器扭簧 | TORSIONAL SPRING | 1 | | | | |
| 8 | GB/T96-6 | 大垫圈 6 | BIG WASHER 6 | 2 | | | | |
| 9 | T15-04040005 | 触发线圈接头 | TIE-IN | 1 | | | | |
| 10 | GB/T6170-M5 | 六角螺母M5 | NUT M5 | 1 | | | | |
| 11 | F60-05000020 | 油门连杆 | ACCELEROGRAPH CONNECTING ROD | 1 | | | | |
| 12 | F15-07130314W | 阻风门接头 | TIE-IN, CHOKE | 1 | | | | |
| 13 | F60-05000018 | 执行器滑轮 | PULLEY | 1 | | | | |
| 14 | F60-05000017 | 油门执行器从动滑轮 | CHAIN WHEEL, DRIVEN | 1 | | | | |
| 15 | F60-05000014-1 | 油门执行器螺钉A | BOLT A, PULLEY DRIVE | 1 | | | | |
| 16 | T85-00010010 | 油门滑轮 | PULLEY , ACCELEROGRAPH | 1 | | | | |
| 17 | F60-00000008 | 油门摆杆座 | BRACKET , ACCELEROGRAPH | 1 | | | | |
| 18 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 4 | | | | |
| 19 | GB/T97.1-6 | 平垫圈6 | WASHER 6 | 5 | | | | |
| 20 | T85-00010008 | 尼龙垫圈 | WASHER, NYLON | 1 | | | | |
| 21 | F60-00000300 | 油门摆杆组件 | ACCELEROGRAPH BAR ASSY | 1 | | | | |
| 22 | F60-00000006 | 微动开关摇臂 | ROCKER, INCHING SWITCH | 1 | | | | |
| 23 | GB/T5783-M5x14 | 六角螺栓 M5x14 | BOLT M5x14 | 1 | | | | |
| 24 | GB/T97.1-5 | 平垫圈5 | WASHER 5 | 1 | | | | |
| 25 | GB/T848-10 | 小垫圈10 | SMALL WASHER 10 | 1 | | | | |
| 26 | F60-00000205 | 变档衬套 | BUSH, SHIFT GEAR | 2 | | | | |
| 27 | F60-00000204 | 变档支座 | BRACKET, SHIFT ROD | 1 | | | | |
| 28 | T20-03000006 | 变档凸轮柱塞 | PLUNGER, SHIFT CAM | 1 | | | | |
| 29 | T60-00010003 | 柱塞弹簧 | SPRING PLUNGER | 1 | | | | |
| 30 | F60-00000009 | 变档柱塞螺母 | NUT, PLUNGER | 1 | | | | |
| 31 | GB/T91- $\varnothing 2 \times 16$ | 开口销 $\varnothing 2 \times 16$ | PIN $\varnothing 2 \times 16$ | 2 | | | | |
| 32 | F60-00000200 | 变档连杆组件 | CONNECTING LEVER ASSY, SHIFT ROD | 1 | | | | |
| 33 | T20-06000037W | 微动开关 | INCHING SWITCH | 1 | | | | BW |
| 34 | F60-00000007 | 微动开关固定架 | RETAINING PLATE, INCHING SWITCH | 1 | | | | |

Disassembling and Check

1. Remove the rubber plug, corrugated rubber sleeve and throttle cable sheath. Remove the ignition line assembly.
2. Remove the bolts securing the small cover plate of the bottom cover, remove the small cover plate of the bottom cover, and remove the square rubber sealing strip. Remove the opening stop plate and the rectangular rubber plug.
3. Remove the top cover locking handle screw, remove the top cover locking handle and the top cover locking block.
4. Remove the top cover locking handle nylon sleeve A and top cover locking handle nylon sleeve B.
5. Remove corrugated washer.
6. Remove the control cable connector A and remove the bolts of the throttle swing rod seat.
7. Remove the throttle swing rod seat and remove the cotter pin on the throttle swing rod assembly.
8. Remove the shift support, remove the shift linkage assembly, and remove the brake rocker.
9. Check the top cover for cracks, damage or wear. Replace it if necessary.
10. Check the top cover locking handle and the top cover locking block for cracking or damage. Replace it if necessary.
11. Check the corrugated washer and lock handle nylon sleeve A for cracks or damage. Replace it if necessary.
12. Check the throttle swing rod seat and throttle swing for cracks or damage. Replace it if necessary.
13. Check the shift linkage assembly for bending deformation or damage. Replace it if necessary.
14. Check whether the shift cam plunger in the shift support slides flexibly. Replace it if necessary.
15. For back-operation models, check whether the rocker of the micro switch is worn. Check micro switch conductivity. Replace it if necessary.

Steering Handle Decomposition Schematic Diagram



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|----------------------|-------------------------|-----------------------------|-----------|--|--|--|--|---------------|
| 1 | F4-01090300 | 操纵手柄塑胶套组件 | STEERING HANDLE ASSY | 1 | | | | | |
| 2 | GB/T820-M5x25 | 十字槽半沉头螺钉 M5x25 | SCREW M5x25 | 1 | | | | | |
| 3 | GB/T848-10 | 小垫圈 10 | WASHER 10 | 2 | | | | | |
| 4 | F4-01090007 | 压缩弹簧 | SPRING, COMPRESSION | 1 | | | | | |
| 5 | T60-01030101 | 节气门杆芯轴 | THROTTLE LEVER | 1 | | | | | |
| 6 | F4-01090006 | 衬套 | BUSH | 1 | | | | | |
| 7 | T60-01030001 | 操纵手柄 | HANDLE, STEERING | 1 | | | | | |
| 8 | F60-01030100 | 油门推拉索组件 | THROTTLE CABLE ASSY | 1 | | | | | |
| 9 | GB/T889. 2-M12x1. 25 | 非金属嵌件六角锁紧螺母 M12x1. 25 | NUT, SELF-LOCKING M12x1. 25 | 1 | | | | | |
| 10 | GB/T879. 4- Φ 3x16 | 标准型卷制弹性圆柱销 Φ 3x16 | PIN Φ 3x16 | 1 | | | | | |
| 11 | T85-01030102 | 节气门杆齿轮组件 | GEAR ASSY, THROTTLE LEVER | 1 | | | | | |
| 12 | T85-01030002 | 齿轮盖板 | HOUSING, GEAR | 1 | | | | | |
| 13 | T85-01030002-1 | 齿轮盖板嵌件 A | WEDGE A, HOUSING | 1 | | | | | |
| 14 | T60-01030002 | 齿轮盖板嵌件 B | WEDGE B, HOUSING | 1 | | | | | |
| 15 | T85-01030005 | 盖板密封垫 | GASKET | 1 | | | | | |
| 16 | T60-01030003 | 节气门盖板 | COVER, THROTTLE | 1 | | | | | |
| 17 | GB/T818-M6x6 | 十字槽盘头螺钉 M6x6 | SCREW, PAN HEAD M6x6 | 1 | | | | | |
| 18 | JB/T9740. 1-M6 | 直通压注式油杯 M6 | NOPPLE, GREASE | 1 | | | | | |
| 19 | GB/T818-M5x12 | 十字槽盘头螺钉 M5x12 | SCREW, PAN HEAD M5x12 | 4 | | | | | |
| 20 | T85-01030015 | 手柄减磨圈 | ANTIFRICTION RING, HANDLE | 2 | | | | | |
| 21 | T85-01030016 | 手柄垫圈 | WASHER, HANDLE | 2 | | | | | |
| 22 | T85-01030017 | 手柄波形垫圈 | WAVE WASHER, HANDLE | 1 | | | | | |
| 23 | GB/T889. 2-M10x1. 25 | 非金属嵌件六角锁紧螺母 M10x1. 25 | SELF-LOCKING NUT M10x1. 25 | 1 | | | | | |
| 24 | T85-01030007 | 变档手柄尼龙衬套 | BUSH, NYLON | 2 | | | | | |
| 25 | F25-01010009 | 尼龙垫圈 | WASHER, NYLON | 1 | | | | | |
| 26 | T85-01030301 | 手柄托架 | BARCKET | 1 | | | | | |
| 27 | T85-01030013 | 手柄托架尼龙衬套 | BUSH | 1 | | | | | |
| 28 | GB/T97. 1-12 | 平垫圈 12 | WASHER 12 | 1 | | | | | |
| 29 | T85-01030014 | 托架螺栓 M12x1. 25x70 | BOLT M12x1. 25x70 | 1 | | | | | |
| 30 | GB/T5783-M6x16 | 六角螺栓 M6x16 | BOLT M6x16 | 3 | | | | | |
| 31 | T85-01030012 | 档位标牌 | INDICATOR, SHIFT | 1 | | | | | |
| 32 | GB/T93-6 | 弹性垫圈 6 | WASHER, SPRING | 2 | | | | | |
| 33 | GB/T97. 1-6 | 平垫圈 6 | WASHER 6 | 7 | | | | | |
| 34 | T85-01030011 | 变档档位板 | CAM PLATE, HANDLE | 1 | | | | | |
| 35 | JB/T7271. 1-M10x32 | 手柄球 M10x32 | BALL M10x32 | 1 | | | | | |
| 36 | T85-01030010 | 变档弹簧导向套 | GUIDE SLEEVE, SPRING | 1 | | | | | |
| 37 | GB/T308-12 | 钢珠 12 | BALL 12 | 1 | | | | | |
| 38 | T85-01030009 | 变档手柄弹簧 | SPRING | 1 | | | | | |
| 39 | T85-01030500 | 变档手柄组件 | HANDLE ASSY, GEAR SHIFT | 1 | | | | | |
| 40 | GB/T91- Φ 2x12 | 开口销 Φ 2x12 | PIN Φ 2x12 | 1 | | | | | |
| 41 | F60-01030019 | 变档连接杆 | CONNECTING ROD | 1 | | | | | |
| 42 | 10-32-UNF-2B | 六角螺母 10-32-UNF-2B | NUT 10-32-UNF-2B | 1 | | | | | |
| 43 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 3 | | | | | |

Continued

| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|---------------------------|-----------|--|--|--|---------------|
| 44 | T85-01030003 | 握把摩擦块 | FRICTION | 1 | | | | |
| 45 | GB62-M6 | 蝶形螺母 M6 | NUT, WING | 1 | | | | |
| 46 | T85-01030008 | 六角带孔螺栓 M6X25 | BOLT M6X25 | 1 | | | | |
| 47 | F4-04120106 | 钢丝锁圈 | EYELET, STEEL WIRE | 1 | | | | |
| 48 | F60-01030000 | 操舵手柄组件 | HANDLE, STEERING ASSY | 1 | | | | |
| 49 | T15-01020003 | 急停开关组件 | STOPER, HANG ROPE ASSY | 1 | | | | |
| 50 | F4-01090401 | 引擎停止安全索 | ENGINE STOP SWITCH ASSY | 1 | | | | |
| 51 | F60-01000100BW | 启动开关总成 | START SWITCH ASSY | 1 | | | | |
| 52 | T85-01010701BW | 启动开关上盖 | UPPER COVER, START SWITCH | 1 | | | | |
| 53 | GB/T818-M6x10 | 十字槽盘头螺钉 M6x10 | SCREW, PAN HEAD M6x10 | 1 | | | | |
| 54 | T85-01010702BW | 启动开关下盖 | LOWER COVER, START SWITCH | 1 | | | | |
| 55 | F60-01000101BW | 启动开关 | START SWITCH | 1 | | | | |
| 56 | T85-01010705BW | 导线线卡 B | WIRE CLIP B | 1 | | | | |

Disassembling and Check


1. Remove the handle bracket, remove the shift handle and remove the Steering handle.
2. Remove the throttle cable assembly.
3. Remove the cotter pin and remove the resistance adjustment knob.
4. Remove the throttle grip.
5. Remove the throttle cover and throttle lever.
6. Remove the engine emergency stop switch.
7. Check the steel ball 12 on the shift handle assembly and the shift handle spring for wear, fracture and sticking. Replace it if necessary.
8. Check the Steering handle for cracks or damage. Replace it if necessary.
9. Check the handle anti-wear ring and waveform washer for cracks or damage. Replace it if necessary.
10. Check the cable in the throttle cable assembly for wear or fracture. Replace it if necessary.
11. Check the teeth on the throttle lever gear assembly for wear or missing. If yes, replace it.
12. Check the conductivity of the engine emergency stop switch; If it does not conform to the regulations, replace it.

Remove locking plate: Conductive
 Install locking plate: Not conductive
 Press the switch button: Conductive




Upper casing unit and Brackets


Decomposition Schematic Diagram



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|------------------------------|-----------|--|--|--|---------------|
| 1 | F60-02010002 | 排气歧管座油封 18x32x9 | OIL SEAL 18x32x9 | 1 | | | | |
| 2 | F25-00000014 | 定位销 \varnothing 8x12 | PIN \varnothing 8x12 | 2 | | | | |
| 3 | F15-04000005 | 水嘴 | WATER NOZZLE | 1 | | | | |
| 4 | F60-02010001 | 排气歧管座 | SEAT, OUTLET MANIFOLD | 1 | | | | |
| 5 | T85-00000012 | 六角螺栓 M10x1.25x45 | BOLT M10x1.25x45 | 6 | | | | |
| 6 | GB/T97.1-10 | 平垫圈 10 | WASHER 10 | 6 | | | | |
| 7 | F60-02010013 | 排气导管密封垫 | GASKET, EXHAUST PIPE | 1 | | | | |
| 8 | F60-02010007 | 排气导管 | EXHAUST PIPE | 1 | | | | |
| 9 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 9 | | | | |
| 10 | GB/T5782-M6x65 | 六角螺栓 M6x65 | BOLT M6x65 | 3 | | | | |
| 11 | F60-02010012 | 排气管密封圈 | RUBBER RING, EXHAUST PIPE | 1 | | | | |
| 12 | F60-02010008 | 排气隔板上密封垫 | UPPER GASKET, CLAPBOARD | 1 | | | | |
| 13 | F25-04000007 | 定位销 \varnothing 4x10 | PIN \varnothing 4x10 | 2 | | | | |
| 14 | F60-02010009 | 排气隔板 | CLAPBOARD, EXHAUST | 1 | | | | |
| 15 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 6 | | | | |
| 16 | F60-02010010 | 排气隔板下密封垫 | LOWER GASKET, CLAPBOARD | 1 | | | | |
| 17 | F60-02010011 | 排气歧管 | OUTLET MANIFOLD | 1 | | | | |
| 18 | F60-02000008 | 排气歧管密封圈 | RUBBER RING, OUTLET MANIFOLD | 1 | | | | |
| 19 | F15-00000006 | 定位销 \varnothing 6x12 | PIN \varnothing 6x12 | 2 | | | | |
| 20 | F60-02000001 | 水上装置壳体 | UPPER CASING | 1 | | | | |
| 21 | F40-00000002 | 水上装置橡胶堵塞 | RUBBER PLUG, UPPER CASING | 1 | | | | |
| 22 | T36-02000006 | 驱动轴衬套橡胶套 | RUBBER BUSHING | 1 | | | | |
| 23 | F60-02000003 | 驱动轴衬套 | BUSHING, DRIVE SHAFT | 1 | | | | |
| 24 | GB/T893.1-36 | A型孔用弹性挡圈 36 | CIRCLIP 36 | 1 | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------------|-------------------------------|-----------|--|--|--|--|---------------|
| 1 | F60-05000021 | 机油尺 | OIL LEVEL | 1 | | | | | |
| 2 | F60-02010003 | 排气歧管座垫 | GASKET, OUTLET MANIFOLD | 1 | | | | | |
| 3 | F60-02000005 | 橡胶导管 A | RUBBER GUIDE A | 1 | | | | | |
| 4 | F60-02000006 | 橡胶导管 B | RUBBER GUIDE B | 1 | | | | | |
| 5 | F60-02010006 | 油底壳 | OIL PAN | 1 | | | | | |
| 6 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 12 | | | | | |
| 7 | GB/T5783-M8x30 | 六角螺栓 M8x30 | BOLT M8x30 | 4 | | | | | |
| 8 | F15-04000003 | 放油螺塞垫片 | WASHER, BOLT | 1 | | | | | |
| 9 | F15-04000002 | 放油螺塞 | BOLT, OIL DRAIN | 1 | | | | | |
| 10 | F60-02000009A | 放油口胶套 | JACKET, OIL DRAIN | 1 | | | | | |
| 11 | F15-00000006 | 定位销 $\varnothing 6 \times 12$ | PIN $\varnothing 6 \times 12$ | 2 | | | | | |
| 12 | F60-02010004 | 粗滤器支架 | BRACKET, COARSE STRAINER | 1 | | | | | |
| 13 | JASO F404 24-012 | O 形圈 12.5x2.4 | O-RING 12.5x2.4 | 1 | | | | | |
| 14 | F60-02010005 | 粗滤器组件 | COARSE STRAINER ASSY | 1 | | | | | |
| 15 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 9 | | | | | |
| 16 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 9 | | | | | |
| 17 | GB/T5782-M8x80 | 六角螺栓 M8x80 | BOLT M8x80 | 8 | | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|----------------------|-------------------------|----------------------------------|-----------|--|--|--|--|---------------|
| 1 | F60-02000011 | 长螺栓 | LONG BOLT | 2 | | | | | |
| 2 | F60-02000010 | 减震器垫板 | PLATE, ABSORBER | 1 | | | | | |
| 3 | F60-02020000 | 双孔减震器组件 | SHOCK ABSORBER ASSY, DOUBLE HOLE | 1 | | | | | |
| 4 | GB/T5783-M8x30 | 六角螺栓 M8x30 | BOLT M8x30 | 7 | | | | | |
| 5 | GB/T97. 1-8 | 平垫圈 8 | WASHER 8 | 9 | | | | | |
| 6 | F60-01020000 | 操舵托架组件 | BRACKET ASSY | 1 | | | | | |
| 7 | T85-01020008 | 双头螺栓 M10x1. 25x28 | BOLT M10x1. 25x28 | 2 | | | | | |
| 8 | GB/T889. 1-M8x1. 25 | I 型非金属嵌件六角锁紧螺母 M8x1. 25 | LOCK NUT M8x1. 25 | 2 | | | | | |
| 9 | GB/T97. 1-10 | 平垫圈 10 | WASHER 10 | 2 | | | | | |
| 10 | GB/T889. 2-M10x1. 25 | I 型非金属嵌件六角锁紧螺母M10x1. 25 | LOCKNUT M10x1. 25 | 2 | | | | | |
| 11 | F60-01010104 | 支撑架组件 B | SUPPORTING ASSY B | 1 | | | | | |
| 12 | T85-01010203 | 支撑架尼龙衬套 | BUSH, NYLON | 2 | | | | | |
| 13 | F60-01010002 | 夹紧托架(右) | BRACKET, CLAMP(RIGHT) | 1 | | | | | |
| 14 | T85-01010003 | 接地钢索 A | WIRE, LEAD A | 1 | | | | | |
| 15 | GB/T818-M6x10 | 十字槽盘头螺钉 M6x10 | SCREW M6x10 | 1 | | | | | |
| 16 | F15-01010007 | 托架夹紧 螺母 | NUT | 2 | | | | | |
| 17 | F25-01010011 | 塑料装饰 螺母 | PLASTIC NUT | 2 | | | | | |
| 18 | F60-01010004 | 螺管尼龙衬套 | BUSH, NYLON | 2 | | | | | |
| 19 | JB/T7940. 1-M6 | 直通式压注油杯 M6 | NIPPLE, GREASE | 3 | | | | | |
| 20 | T85-01010210 | 油杯胶帽 | CAP, GREASE NIPPLE | 3 | | | | | |
| 21 | GB/T879. 2-3x16 | 轻型直槽弹性圆柱销 3x16 | PIN, SPRING | 2 | | | | | |
| 22 | T85-01010206 | 支撑架摆杆组件 | COLLAR, DISTANCE | 1 | | | | | |
| 23 | F60-01010103 | 支撑架尼龙衬套 | BUSH, NYLON | 2 | | | | | |
| 24 | T85-01010207 | 摆杆拉簧 | SPRING | 1 | | | | | |
| 25 | T85-01010208 | 拉簧支架 | PLATE | 1 | | | | | |
| 26 | GB/T5783-M6x10 | 六角螺栓 M6x10 | BOLT M6x10 | 1 | | | | | |
| 27 | F60-01010101 | 旋转支架 | BRACKET | 1 | | | | | |
| 28 | T85-01020002 | 旋转支架上垫圈 | WASHER | 1 | | | | | |
| 29 | T85-01020003 | 旋转支架上衬套 | BUSH | 1 | | | | | |
| 30 | T85-01020004 | 旋转支架 O 形圈 | O-RING | 2 | | | | | |
| 31 | T85-01020005 | 旋转支架衬套 | BUSH | 2 | | | | | |
| 32 | F60-01010102 | 支撑架组件 A | SUPPORTING ASSY A | 1 | | | | | |
| 33 | GB/T5783-M6x20 | 六角螺栓 M6x20 | BOLT M6x20 | 2 | | | | | |
| 34 | GB/T97. 1-6 | 平垫圈 6 | WASHER 6 | 2 | | | | | |
| 35 | F60-01010200 | 起翘传感器组件 | RAISE SENSOR ASSY | 1 | | | | | |
| 36 | F60-01010001 | 夹紧托架(左) | BRACKET, CLAMP(LEFT) | 1 | | | | | |
| 37 | F60-01010003A | 夹紧托架双头螺管 | DOUBLE-EDGED TUBE | 1 | | | | | |
| 38 | T85-01020006 | 旋转支架下衬套 | BUSH | 1 | | | | | |
| 39 | F60-00000005 | 减震器外盖 | COVER, ABSORBER | 2 | | | | | |
| 40 | F60-00000004 | 螺母护盖 | NUT COVER | 2 | | | | | |
| 41 | F60-00000001 | 减震器螺钉 | BOLT, ABSORBER | 2 | | | | | |
| 42 | T85-00000002 | 螺栓垫圈 A | WASHER A | 2 | | | | | |
| 43 | T36-02020003 | 橡胶垫片 | RUBBER WASHER | 2 | | | | | |

Continued

| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|-------------------|-------------------------|-----------------------------|-----------|--|--|--|---------------|
| 44 | F60-0000003 | 减震器垫板 | WASHER, ABSORBER | 2 | | | | |
| 45 | F60-0000100 | 左右减震器组件 | ABSORBER ASSY (LEFT, RIGHT) | 2 | | | | |
| 46 | F60-0000002 | 橡胶垫圈 | RUBBER WASHER | 2 | | | | |
| 47 | T85-0000020 | 减震器垫圈 | WASHER | 4 | | | | |
| 48 | F60-0100001 | 减震器固定块 | ABSORBER BLOCK | 1 | | | | |
| 49 | GB/T6170-M12x1.25 | 六角螺母 M12x1.25 | NUT M12x1.25 | 2 | | | | |
| 50 | F60-0200002 | 接地钢索 | WIRE, LEAD | 1 | | | | |
| 51 | T85-01020010 | 卡圈 | CTRCLIP | 1 | | | | |

Disassembling and Check of Bracket

1. Remove the outer cover of the left and right absorbers, remove the left and right absorbers and the retaining nuts of the double-hole absorbers.
2. Remove the water unit, oil pan and outlet manifold socket completely from the bracket
3. Remove the bracket clamp nut and clamp the bracket double-headed screw tube.
4. Disconnect the ground cable A and remove clamping bracket.
5. Remove support frame assembly A & B, remove the nylon bushing.
6. Remove fixed block limit circlip of the absorber, remove fixed block of the absorber.

Attention:

The absorber fixed block and the steering bracket assembly are splined and tightly connected. Please be careful when disassembling and installing it.

Avoid accidental injuries; Do not disassemble unless necessary.


7. Pull out the steering bracket assembly and remove the liner, bushing and O-ring.
8. Check the rotary bracket and clamping bracket for cracks or damage. Replace it if necessary.
9. Check the bushing and liner; If damaged or cracked, replace it.
10. Check the support frame assembly A&B for deformation or damage. Replace it if necessary.
11. Check the rubber of the left and right absorbers for aging, cracking or degumming. Replace it if necessary.

Disassembling and Check of Water Unit

1. Drain the oil.
2. Remove the mounting bolts on and under the water, and remove the water unit.
3. Remove outlet manifold socket, remove the oil pan.
4. Remove coarse filter assembly and coarse filter support from the outlet manifold seat.
5. Remove the exhaust pipe, oil drain screw, oil drain rubber sleeve and rubber conduit A&B and the outlet manifold from the oil pan

6. Remove the exhaust partition and exhaust duct from the oil pan.
7. Remove the double-hole absorber, exhaust partition, round rubber ring for water pipe and the water pipe.
8. Check the water unit casing and oil pan for cracks or damage. Replace it if necessary.
9. Check the exhaust partition for damage or cracks. Replace it if necessary.
10. Check the exhaust duct and manifold for cracks or damage. Replace it if necessary.
11. Check the exhaust duct sealing ring and the outlet manifold sealing ring for aging or cracking. Replace it if necessary.

Manual Tilting Device Disassembly Schematic Diagram




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|-------------------------|-----------|--|--|--|---------------|
| 1 | GB/T894.1-16 | 轴用弹性挡圈 16 | CIRCLIP 16 | 2 | | | | |
| 2 | T60-01010005 | 销轴衬套 B | BUSH B | 2 | | | | |
| 3 | T60-01010006 | 起翘销轴 | PIN UPPER SHOCK MOUNT | 1 | | | | |
| 4 | T60-01010004 | 销轴衬套 A | BUSH A | 1 | | | | |
| 5 | T60-01020001D | 氮气缸手柄 | HANDEL | 1 | | | | |
| 6 | T60-01020000 | 手动气缸组件 | TRIM & TILT ASSY | 1 | | | | |
| 7 | F40-00000006D | 气缸阳极 | ANODE | 1 | | | | |
| 8 | GB/T820-M6x25 | 十字槽半沉头螺钉 M6x25 | SCREW M6x25 | 1 | | | | |
| 9 | T60-01010101 | 夹紧托架(左) | BRACKET, CLAMP (LEFT) | 1 | | | | |
| 10 | T85-01010403 | 锥形弹簧 | CONICAL SPRING | 1 | | | | |
| 11 | T85-01010400 | 角度限位杆组件 | LIMITATIVE ROD ASSY | 1 | | | | |

Disassembling

1. Fully tilt the outboard motor upwards and lower the support frame to support the outboard motor.
2. Remove the steel wire retaining ring for the shaft and remove the tilting pin shaft.
3. Remove the bolt and remove the hydraulic tilting positioning shaft.
4. Removing the manual cylinder assembly

Hydraulic Tilting Device

Disassembly Schematic Diagram



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|----------------------|-------------------------|-------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T5785-M10x1.25x30 | 六角螺栓 M10x1.25x30 | BOLT M10x1.25x30 | 2 | | | | | |
| 2 | F60-0000015 | 厚垫圈 10 | THICK WASHER 10 | 2 | | | | | |
| 3 | T85-0000016 | 起翘销轴 | PIN UPPER SHOCK MOUNT | 1 | | | | | |
| 4 | T85-0000017 | 销轴衬套 A | BUSH A | 2 | | | | | |
| 5 | T85-01010007 | 手动气缸衬套 | BUSH | 1 | | | | | |
| 6 | GB/T894.1-18 | 轴用弹性挡圈 18 | CIRCLIP 18 | 1 | | | | | |
| 7 | E10-01010008 | 起翘机构阳极 | ANODE | 3 | | | | | |
| 8 | GB/T5783-M6x25 | 六角螺栓 M6x25 | BOLT M6x25 | 6 | | | | | |
| 9 | F60-0000012 | 定位轴衬套 A | BUSH A | 1 | | | | | |
| 10 | F60-0000011 | 液压起翘定位轴 | SHAFT | 1 | | | | | |
| 11 | F60-0000013 | 定位轴衬套 B | BUSH B | 1 | | | | | |

Disassembling


1. Fully tilt the outboard motor upwards and lower the support frame to support the outboard motor.
2. Remove the steel wire retaining ring for the shaft and remove the tilting pin shaft.
3. Remove the bolt and remove the hydraulic tilting positioning shaft.
4. Remove the hydraulic tilting assembly.

Oil Level Check

1. Position and secure the hydraulic tilting device vertically.
2. Connect the tilting motor wire of the hydraulic tilting device to the battery.
3. Extend the push rod completely, remove the oil screw and observe the oil level.

Note:

The liquid level should be at the edge of the oil hole,



1. Oil drain screw

4. If necessary, add oil to the edge of the oil hole.
5. Install and tighten the oil drain screw.
Specified torque: 6.5 Nm

Discharge Air from Oil Circuit of the Hydraulic Tilting Device


After adding oil, discharge the excess air in the oil.

1. . Connect the tilting motor wire of the hydraulic tilting device to the battery.

2. Extend the push rod completely.
3. Change the positive and negative wire connections.
4. Compress the push rod completely.
5. Repeat steps 1 to 4 to move the push rod up and down for 4 to 5 times.
6. Extend the push rod completely, remove the oil screw and observe the oil level.
7. If necessary, repeat the above steps until the oil level is correct.
8. Install and tighten the oil drain screw.
Specified torque: 6.5 Nm

If the hydraulic lifting device needs to be vented when installed on the outboard outboard motor, please follow the following steps.

1. Turn the hand control valve counterclockwise until it cannot turn.




1. Hand control valve


2. Tilt the outboard motor completely upward and then lower it downward by its own gravity. Repeat 4 ~ 5 times.
3. Turn the hand control valve clockwise until it cannot turn.
4. Wait for 5 minutes to stabilize the oil.
5. Press and hold the tilt switch until the outboard motor is fully tilted.
6. Wait for 5 minutes to stabilize the oil.
7. Remove the oil drain screw and observe the oil level.
8. If necessary, repeat the above steps until the oil level is correct.
9. Install and tighten the oil drain screw.
Specified torque: 6.5 Nm

Lower casing Part

Decomposition Schematic Diagram(D/T model)




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|---------------------------------------|---|-----------|--|--|--|--|---------------|
| 1 | T40-04000203 | 水管下密封圈 | SEAL | 2 | | | | | |
| 2 | F60-02000007 | 水管 | WATER PIPE | 1 | | | | | |
| 3 | T40-02000002 | 水管导向套 | GUIDE BUSHING, WATER PIPE | 1 | | | | | |
| 4 | T40-04000204 | 水管尼龙导向套 | NYLON BUSHING, WATER PIPE | 1 | | | | | |
| 5 | T40-04000014 | 水封 | WATER ENVELOP | 1 | | | | | |
| 6 | T40-04000013 | 水封垫板 | PLATE, WATER ENVELOP | 1 | | | | | |
| 7 | GB/T5782-M8x35 | 六角螺栓 M8x35 | BOLT M8x35 | 1 | | | | | |
| 8 | GB/T93-8 | 弹簧垫圈 8 | SPRING-WASHER 8 | 2 | | | | | |
| 9 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 3 | | | | | |
| 10 | F15-00000006 | 定位销 $\phi 6 \times 12$ | DOWEL PIN $\phi 6 \times 12$ | 2 | | | | | |
| 11 | GB/T97.1-10 | 平垫圈 10 | WASHER 10 | 4 | | | | | |
| 12 | F40-02000010 | 六角螺栓 M10x1.25x40 | BOLT M10x1.25x40 | 4 | | | | | |
| 13 | GB/T5782-M8x65 | 六角螺栓 M8x65 | BOLT M8x65 | 1 | | | | | |
| 14 | GB/T5783-M8x25 | 六角螺栓 M8x25 | BOLT M8x25 | 1 | | | | | |
| 15 | T40-00000010 | 航向调整片 | ANODE | 1 | | | | | |
| 16 | T40-00000009 | 水下阳极 A | ANODE A, LOWER CASING | 1 | | | | | |
| 17 | T40-04000018 | 螺旋桨垫块 | SPACER, PROPELLER | 1 | | | | | |
| 18 | T40-04070000-13 | 螺旋桨体组件 3-11 $\frac{1}{8} \times 13''$ | PROPELLER ASSY 3-11 $\frac{1}{8} \times 13''$ | 1 | | | | | |
| | T40-04070000-12 | 螺旋桨体组件 3-11 $\frac{3}{8} \times 12''$ | PROPELLER ASSY 3-11 $\frac{3}{8} \times 12''$ | | | | | | |
| | T40-04070000-11 | 螺旋桨体组件 3-11 $\frac{5}{8} \times 11''$ | PROPELLER ASSY 3-11 $\frac{5}{8} \times 11''$ | | | | | | |
| 19 | T40-04000019 | 螺旋桨衬套 A | BUSH A, PROPELLER | 1 | | | | | |
| 20 | T40-04000020 | 螺旋桨衬套 B | BUSH B, PROPELLER | 1 | | | | | |
| 21 | T40-04000021 | 开槽六角螺母 | NUT | 1 | | | | | |
| 22 | GB/T91-3.2x25 | 开口销 $\phi 3.2 \times 25$ | COTTER PIN $\phi 3.2 \times 25$ | 1 | | | | | |




| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|----------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T5783-M8x30 | 六角螺栓 M8x30 | BOLT M8x30 | 4 | | | | | |
| 2 | T40-04000012 | 水泵壳体压板 | PLATE, WATER PUMP | 4 | | | | | |
| 3 | F60-04000401 | 水泵壳体 | SHELL , WATER PUMP | 1 | | | | | |
| 4 | T40-04000202 | 水泵内壳 | INNER SHELL, WATER PUMP | 1 | | | | | |
| 5 | F60-04000300 | 水泵叶轮组件 | IMPELLER ASSY, WATER PUMP | 1 | | | | | |
| 6 | T40-04000205 | 壳体 O 形密封圈 | O-RING | 1 | | | | | |
| 7 | F25-04000007 | 定位销 Φ4x10 | DOWEL PIN Φ4x10 | 2 | | | | | |
| 8 | F60-04000009 | 外挡板 | OUTER PLATE | 1 | | | | | |
| 9 | T40-04000010 | 水泵座密封垫 | GASKET , WATER PUMP | 1 | | | | | |
| 10 | F60-04000008 | 油封盖 | COVER , OIL SEAL | 1 | | | | | |
| 11 | T40-04040001 | 油封壳体 A | CASING A, OIL SEAL | 1 | | | | | |
| 12 | JASO F404 24-50 | 油封壳体 A O 型密封圈 | O-RING, CASING A | 1 | | | | | |
| 13 | F25-04010003 | 驱动轴油封 22x36x6 | OIL SEAL 22x36x6 | 4 | | | | | |
| 14 | T40-04000008 | 大垫圈 | BIG WASHER | 1 | | | | | |
| 15 | F60-04010000 | 驱动轴组件 | DRIVE SHAFT ASSY | 1 | | | | | |
| 16 | F25-04000015 | 半圆键 | WOODRUFF KEY | 1 | | | | | |
| 17 | T40-04000027 | 驱动轴圆锥滚子轴承 32005 | BEARING 32005 | 1 | | | | | |
| 18 | T40-04000003 | 驱动轴填隙片 | SHIM | | | | | | |
| | T40-04000003-1 | 填隙片 (T=0.10 毫米) | SHIM (T = 0.10mm) | | | | | | |
| | T40-04000003-2 | 填隙片 (T=0.12 毫米) | SHIM (T = 0.12mm) | | | | | | |
| | T40-04000003-3 | 填隙片 (T=0.15 毫米) | SHIM (T = 0.15mm) | | | | | | |
| | T40-04000003-4 | 填隙片 (T=0.18 毫米) | SHIM (T = 0.18mm) | | | | | | |
| | T40-04000003-5 | 填隙片 (T=0.30 毫米) | SHIM (T = 0.30mm) | | | | | | |
| | T40-04000003-6 | 填隙片 (T=0.40 毫米) | SHIM (T = 0.40mm) | | | | | | |
| | T40-04000003-7 | 填隙片 (T=0.50 毫米) | SHIM (T = 0.50mm) | | | | | | |
| 19 | T40-04000002 | 长尼龙套管 | BUSHING, NYLON | 1 | | | | | |
| 20 | T40-04000026 | 滚针轴承 B 1416 | BEARING B 1416 | 1 | | | | | |
| 21 | T85-04000011 | 变档凸轮油封 9x19x5 | OIL SEAL 9x19x5, CAM SHAFT | 1 | | | | | |
| 22 | F60-04000101 | 变档凸轮盖板 | PLATE, CAM SHAFT | 1 | | | | | |
| 23 | JASO F404 31-035 | O 型密封圈 34.4x3.1 | O-RING 34.4x3.1 | 1 | | | | | |
| 24 | JASO F404 19-007 | O 型密封圈 6.8x1.9 | O-RING 6.8x1.9 | 1 | | | | | |
| 25 | GB/T896-8 | 开口挡圈 8 | CIRCLIP 8 | 1 | | | | | |
| 26 | F60-04000004 | 变档凸轮轴 | CAMSHAFT | 1 | | | | | |
| 27 | F4-03000023 | 注油孔螺塞 | PLUG, HOLE OIL | 1 | | | | | |
| 28 | F4-03000024 | 注油孔螺塞垫 | GASKET | 2 | | | | | |
| 29 | GB/T889.1-M5 | 非金属嵌件 六角 锁紧 螺母 M5 | LOCKING NUT M5 | 1 | | | | | |
| 30 | T40-04000023 | 进水口 B | WATER INLET B | 1 | | | | | |
| 31 | F25-04000031 | 放油螺塞 | PLUG, OIL RELEASE | 1 | | | | | |
| 32 | F60-04000001 | 水下装置壳体 | LOWER CASING | 1 | | | | | |
| 33 | T40-04000006 | 小齿轮螺母 M12X1.25 | NUT, PINION | 1 | | | | | |
| 34 | F60-04000002 | 小齿轮 | PINION | 1 | | | | | |
| 35 | T40-04000022 | 进水口 A | WATER INLET A | 1 | | | | | |
| 36 | GB/T820-M5x30 | 十字槽半沉头螺钉 M5x30 | SCREW, PAN HEAD M5x30 | 1 | | | | | |

| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|--------------------|----------------------------------|--------------------------|-----------|--|--|--|---------------|
| 37 | F60-0400003 | 变档凸轮 | CAM, SHIFT | 1 | | | | |
| 38 | T40-0400004 | 正档齿轮填隙片 | SHIM | | | | | |
| | T40-0400004-1 | 填隙片 (T = 0.10 毫米) | SHIM (T = 0.10mm) | | | | | |
| | T40-0400004-2 | 填隙片 (T = 0.12 毫米) | SHIM (T = 0.12mm) | | | | | |
| | T40-0400004-3 | 填隙片 (T = 0.15 毫米) | SHIM (T = 0.15mm) | | | | | |
| | T40-0400004-4 | 填隙片 (T = 0.18 毫米) | SHIM (T = 0.18mm) | | | | | |
| | T40-0400004-5 | 填隙片 (T = 0.30 毫米) | SHIM (T = 0.30mm) | | | | | |
| | T40-0400004-6 | 填隙片 (T = 0.40 毫米) | SHIM (T = 0.40mm) | | | | | |
| | T40-0400004-7 | 填隙片 (T = 0.50 毫米) | SHIM (T = 0.50mm) | | | | | |
| 39 | KOYO HI-CAP 332/32 | 圆锥滚子轴承 332/32 | ROLLER BEARING 332/32 | 1 | | | | |
| 40 | F60-0400600 | 正档齿轮组件 | FORWARD GEAR ASSY | 1 | | | | |
| 41 | F60-0402005 | 变档柱塞 | PLUNGER, SHIFT | 1 | | | | |
| 42 | T36-03000403 | 离合器垫块 | SPACER, CLUTCH | 1 | | | | |
| 43 | F60-0402002 | 离合器弹簧 | SPRING, CLUTCH | 1 | | | | |
| 44 | F60-0402003 | 爪型离合器 | CLUTCH, DOG | 1 | | | | |
| 45 | T40-04050004 | 离合器销 $\varnothing 6.3 \times 33$ | PIN, CLUTCH | 1 | | | | |
| 46 | T40-04050005 | 离合器簧环 | RING, CLUTCH | 1 | | | | |
| 47 | F60-0402001 | 螺旋桨轴 | SHAFT, PROPELLER | 1 | | | | |
| 48 | F60-0402000 | 螺旋桨轴组件 | PROPELLER SHAFT ASSY | 1 | | | | |
| 49 | T40-04050007 | 倒档齿轮垫圈 | WASHER, REVERSE GEAR | 1 | | | | |
| 50 | F60-04000500 | 倒档齿轮 | GEAR, REVERSE | 1 | | | | |
| 51 | T40-04060005 | 倒档齿轮填隙片 | SHIM | | | | | |
| | T40-04060005-1 | 填隙片 (T = 0.10 毫米) | SHIM (T = 0.10mm) | | | | | |
| | T40-04060005-2 | 填隙片 (T = 0.12 毫米) | SHIM (T = 0.12mm) | | | | | |
| | T40-04060005-3 | 填隙片 (T = 0.15 毫米) | SHIM (T = 0.15mm) | | | | | |
| | T40-04060005-4 | 填隙片 (T = 0.18 毫米) | SHIM (T = 0.18mm) | | | | | |
| | T40-04060005-5 | 填隙片 (T = 0.30 毫米) | SHIM (T = 0.30mm) | | | | | |
| | T40-04060005-6 | 填隙片 (T = 0.40 毫米) | SHIM (T = 0.40mm) | | | | | |
| | T40-04060005-7 | 填隙片 (T = 0.50 毫米) | SHIM (T = 0.50mm) | | | | | |
| 52 | T40-04000025 | 深沟球轴承 6007 | BALL BEARING 6007 | 1 | | | | |
| 53 | F60-04030000 | 水下装置壳体盖组件 | COVER ASSY, LOWER CASING | 1 | | | | |
| 54 | T40-04060002 | 水下装置壳体盖 O 型密封圈 A | O-RING A, COVER | 1 | | | | |
| 55 | T40-04060003 | 水下装置壳体盖 O 型密封圈 B | O-RING B, COVER | 2 | | | | |
| 56 | T40-04060001 | 水下装置壳体盖 | COVER, LOWER CASING | 1 | | | | |
| 57 | T40-04000028 | 滚针轴承 2220 | QUILL BEARING | 1 | | | | |
| 58 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 2 | | | | |
| 59 | GB/T5783-M8x25 | 六角螺栓 M8x25 | BOLT, HEXAGON M8x25 | 2 | | | | |
| 60 | F60-04000000 | 水下装置组件 | LOWER CASING ASSY | 1 | | | | |



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|-----------------------|-------------------------|------------------------------|-----------|--|--|--|--|---------------|
| 1 | T40-04000203 | 水管下密封圈 | SEAL | 1 | | | | | |
| 2 | F60-02000007BF | 水管 | WATER PIPE | 1 | | | | | |
| | T40-02000002 | 水管导向套 | GUIDE BUSHING, WATER PIPE | 1 | | | | | |
| 3 | | | | | | | | | |
| 4 | T85-02000002 | 水管导向套 | ORIENTED BUSHING, WATER PIPE | 1 | | | | | |
| 5 | GB/T845-ST4. 2x14 | 十字槽盘头自攻螺钉 ST4. 2x14 | SCREW ST4. 2x14 | 2 | | | | | |
| 6 | T85-04000405 | 水管下导向套 | LOWER BUSHING, WATER PIPE | 1 | | | | | |
| 7 | T85-04000404 | 水管下衬圈 | SEAL, WATER PIPE | 1 | | | | | |
| 8 | T85-00000012 | 凸缘螺栓 M10x1. 25x45 | BOLT M10x1. 25x45 | 1 | | | | | |
| 9 | T85-04000013 | 水封 | WATER ENVELOP | 1 | | | | | |
| 10 | T40-04000013 | 水封垫板 | PLATE, WATER ENVELOP | 1 | | | | | |
| 11 | F15-00000006 | 定位销 ϕ 6x12 | DOWEL PIN ϕ 6x12 | 2 | | | | | |
| 12 | GB/T97. 1-10 | 平垫圈 10 | WASHER 10 | 4 | | | | | |
| 13 | GB/T5785-M10x1. 25x40 | 六角螺栓 M10x1. 25x40 | BOLT M10x1. 25x40 | 4 | | | | | |
| 14 | GB/T5783-M8x60 | 六角螺栓 M8x60 | BOLT M8x60 | 1 | | | | | |
| 15 | GB/T97. 1-8 | 平垫圈 8 | WASHER 8 | 1 | | | | | |
| 16 | T85-00000011 | 水下阳极 | ANODE, LOWER CASING | 1 | | | | | |
| 17 | T85-04000024 | 螺旋桨垫块 | SPACER, PROPELLER | 1 | | | | | |
| 18 | T85-04020000 | 螺旋桨组件 | PROPELLER ASSY | 1 | | | | | |
| 19 | T85-04000025 | 螺旋桨 衬套 A | BUSH A, PROPELLER | 1 | | | | | |
| 20 | T85-04000026 | 螺旋桨 衬套 B | BUSH B, PROPELLER | 1 | | | | | |
| 21 | T40-04000021 | 开槽六角螺母 | NUT | 1 | | | | | |
| 22 | GB/T91-3. 5x25 | 开口销 ϕ 3. 5x25 | COTTER PIN ϕ 3. 5x25 | 1 | | | | | |

Decomposition Schematic Diagram (CD/CT model)



| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | | REMARKS 备注 |
|-------------|--------------------|-------------------------|----------------------------|-----------|--|--|--|--|---------------|
| 1 | GB/T5782-M8x50 | 六角螺栓 M8x50 | BOLT M8x50 | 2 | | | | | |
| 2 | GB/T97.1-8 | 平垫圈 8 | WASHER 8 | 4 | | | | | |
| 3 | GB/T5782-M8x60 | 六角螺栓 M8x60 | BOLT M8x60 | 2 | | | | | |
| 4 | F60-04000401BF | 水泵壳体 | SHELL , WATER PUMP | 1 | | | | | |
| 5 | F60-04000402BF | 水泵内壳 | INNER SHELL, WATER PUMP | 1 | | | | | |
| 6 | F60-04000300 | 水泵叶轮组件 | IMPELLER ASSY, WATER PUMP | 1 | | | | | |
| 7 | F25-04000007 | 定位销 Φ4x10 | DOWEL PIN Φ4x10 | 2 | | | | | |
| 8 | F60-04000016BF | 外挡板上密封垫 | UPPER GASKET, OUTER PLATE | 1 | | | | | |
| 9 | F60-04000009BF | 外挡板 | OUTER PLATE | 1 | | | | | |
| 10 | T85-04000015 | 外挡板上密封垫 | LOWER GASKET, OUTER PLATE | 1 | | | | | |
| 11 | F60-04000200BF | 水泵座组件 | WATER PUMP BASE ASSY | 1 | | | | | |
| 12 | F60-04000202BF | 水泵座 | BASE, WATER PUMP | 1 | | | | | |
| 13 | T85-04000204 | 水泵座 O 形圈 46.7x3.1 | O - RING, WATER PUMP BASE | 1 | | | | | |
| 14 | T85-04000202 | 水泵座油封 25x40x6 | OIL SEAL 25x40x6 | 4 | | | | | |
| 15 | T85-04000203 | 油封挡圈 | CIRCLIP, OIL SEAL | 1 | | | | | |
| 16 | T85-04000014 | 水泵座密封垫 | GASKET, WATER PUMP BASE | 1 | | | | | |
| 17 | F60-04010000BF | 驱动轴组件 | DRIVE SHAFT ASSY | 1 | | | | | |
| 18 | F25-04000015 | 半圆键 | SEMICIRCULAR KEY | 1 | | | | | |
| 19 | L44649 H1-CAP KOYO | 驱动轴圆锥滚子轴承 | ROLLER BEARING | 1 | | | | | |
| 20 | T85-04000003-1 | 驱动轴填隙片 (t:0.12 毫米) | SHIM(t:0.12mm) | | | | | | |
| | T85-04000003-2 | 驱动轴填隙片 (t:0.30 毫米) | SHIM(t:0.30mm) | | | | | | |
| | T85-04000003-3 | 驱动轴填隙片 (t:0.40 毫米) | SHIM(t:0.40mm) | | | | | | |
| | T85-04000003-4 | 驱动轴填隙片 (t:0.50 毫米) | SHIM(t:0.50mm) | | | | | | |
| 21 | T85-04000002 | 长尼龙套管 | BUSHING , NYLON | 1 | | | | | |
| 22 | NSK 1620 | 滚针轴承 | QUILL BEARING | 1 | | | | | |
| 23 | GB/T5783-M6x16 | 六角螺栓 M6x16 | BOLT M6x16 | 2 | | | | | |
| 24 | GB/T97.1-6 | 平垫圈 6 | WASHER 6 | 2 | | | | | |
| 25 | T85-04000011 | 变档凸轮油封 9x19x5 | OIL SEAL 9x19x5, CAM SHAFT | 1 | | | | | |
| 26 | T85-04000009 | 变档凸轮盖板 | PLATE, CAM SHAFT | 1 | | | | | |
| 27 | JASO F404 31-50 | 盖板 O 型圈 50x3.1 | O-RING 50x3.1 | 1 | | | | | |
| 28 | GB/T896-8 | 开口挡圈 8 | CIRCLIP 8 | 1 | | | | | |
| 29 | T85-04000008 | 变档凸轮轴 | CAMSHAFT | 1 | | | | | |
| 30 | F4-03000023 | 注油孔螺塞 | PLUG, HOLE OIL | 1 | | | | | |
| 31 | F4-03000024 | 注油孔螺塞垫 | GASKET | 2 | | | | | |
| 32 | GB/T889.1-M5 | 非金属嵌件 六角 锁紧 螺母 M5 | LOCKING NUT M5 | 1 | | | | | |
| 33 | T85-04000023 | 进水口 B | WATER INLET B | 1 | | | | | |
| 34 | F25-04000031 | 放油螺塞 | PLUG, OIL RELEASE | 1 | | | | | |
| 35 | T85-04000001 | 水下装置壳体 | LOWER CASING | 1 | | | | | |
| 36 | T85-04000006 | 小齿轮螺母 | NUT, PINION | 1 | | | | | |
| 37 | T60-04000002 | 小齿轮 | PINION | 1 | | | | | |
| 38 | T85-04000022 | 进水口 A | WATER INLET A | 1 | | | | | |
| 39 | GB/T820-M5x45 | 十字头半沉头螺钉 M5x45 | SCREW M5x45 | 1 | | | | | |
| 40 | T85-04000007 | 变档凸轮 | CAM, SHIFT | 1 | | | | | |

| SN. 参照号码 | PART NO. 零件编号 | DESCRIPTION 零件名称(中文) | DESCRIPTION 零件名称(英文) | QTY 数量 | | | | REMARKS 备注 |
|-------------|------------------|-------------------------|--------------------------|-----------|--|--|--|---------------|
| 41 | T85-0400004-1 | 正档齿轮填隙片 (T=0.10 毫米) | SHIM(t:0.10mm) | | | | | |
| | T85-0400004-2 | 正档齿轮填隙片 (T=0.12 毫米) | SHIM(t:0.12mm) | | | | | |
| | T85-0400004-3 | 正档齿轮填隙片 (T=0.20 毫米) | SHIM(t:0.20mm) | | | | | |
| | T85-0400004-4 | 正档齿轮填隙片 (T=0.30 毫米) | SHIM(t:0.30mm) | | | | | |
| | T85-0400004-5 | 正档齿轮填隙片 (T=0.40 毫米) | SHIM(t:0.40mm) | | | | | |
| | T85-0400004-6 | 正档齿轮填隙片 (T=0.50 毫米) | SHIM(t:0.50mm) | | | | | |
| 42 | KOYO 26882-R/22 | 圆锥滚子轴承 | ROLLER BEARING | 1 | | | | |
| 43 | T60-04000100 | 正档齿轮组件 | FORWARD GEAR ASSY | 1 | | | | |
| 44 | T60-0400008 | 变档柱塞 | PLUNGER, SHIFT | 1 | | | | |
| 45 | T85-04000506 | 离合器垫块 | SPACER, CLUTCH | 1 | | | | |
| 46 | T60-04000502 | 离合器弹簧 | SPRING, CLUTCH | 1 | | | | |
| 47 | T60-04000501 | 爪型离合器 | CLUTCH, DOG | 1 | | | | |
| 48 | T85-04000504 | 离合器销 | PIN, CLUTCH | 1 | | | | |
| 49 | T85-04000505 | 离合器簧环 | RING, CLUTCH | 1 | | | | |
| 50 | T85-04000501 | 螺旋桨轴 | SHAFT, PROPELLER | 1 | | | | |
| 51 | T85-04000500 | 螺旋桨轴组件 | PROPELLER SHAFT ASSY | 1 | | | | |
| 52 | T60-04000601 | 倒档齿轮 | GEAR, REVERSE | 1 | | | | |
| 53 | T85-04000606-1 | 倒档齿轮填隙片 (T=0.12 毫米) | SHIM(t:0.12mm) | | | | | |
| | T85-04000606-2 | 倒档齿轮填隙片 (T=0.20 毫米) | SHIM(t:0.20mm) | | | | | |
| | T85-04000606-3 | 倒档齿轮填隙片 (T=0.30 毫米) | SHIM(t:0.30mm) | | | | | |
| | T85-04000606-4 | 倒档齿轮填隙片 (T=0.40 毫米) | SHIM(t:0.40mm) | | | | | |
| | T85-04000606-5 | 倒档齿轮填隙片 (T=0.50 毫米) | SHIM(t:0.50mm) | | | | | |
| 54 | T85-04000604 | 倒档齿轮垫块 | SPACER, REVERSE GEAR | 1 | | | | |
| 55 | NTN 6207 15 C-3 | 深沟球轴承 | BALL BEARING | 1 | | | | |
| 56 | T60-04000600 | 水下装置壳体盖组件 | COVER ASSY, LOWER CASING | 1 | | | | |
| 57 | T85-04000603 | 水下壳盖 O 形圈 | O-RING, COVER | 1 | | | | |
| 58 | T55-04000601A | 水下装置壳体盖 | COVER, LOWER CASING | 1 | | | | |
| 59 | NTN HK 2526NS | 滚针轴承 | QUILL BEARING | 1 | | | | |
| 60 | T85-04000027 | 壳盖定位件 | PIECE, ORIENTATION | 1 | | | | |
| 61 | T85-04000020 | 锁止垫圈 | WASHER, LOCKED | 1 | | | | |
| 62 | T85-04000021 | 壳盖螺母 | CROWN NUT | 1 | | | | |
| 63 | F60-0400000BF | 水下装置组件 (L) | LOWER CASING ASSY(L) | 1 | | | | |

Disassembling and Check

1. Remove the water pipe.
2. Remove the water pump casing.
3. Remove the impeller and pump inner casing.
4. Remove the semicircular key and outer baffle.
5. Check the water pump casing and outer baffle for cracks, twists or damages. Replace it if necessary.
6. Check the water pump inner casing and impeller for cracking, deformation, burning or wear. Replace it if necessary.
7. Drain the gear oil.

8. Remove the cotter pin; Place the shift lever in neutral position. Place a piece of wood between the swirl plate and the propeller, to prevent the propeller from rotating freely.
9. Remove the slotted hexagon nut, remove the propeller, remove the cushion block.
10. Remove the anode and water inlet.
11. Remove cover for the Lower casing unit casing.
Remove reverse gear and shim and remove oil seal.
12. Remove the propeller shaft assembly.
13. Remove the shift plunger.
14. Remove the clutch ring, clutch pin and claw clutch. Remove the clutch spring.
15. Remove the oil seal casing A.
Remove water pump seat (CD/CT model)
16. Remove the pinion nut with an internal splined wrench and remove the drive shaft.




17. Remove shift cam, remove forward gear.
Remove shift cam cover plate and remove shift cam. Remove the forward gear (CD/CT)
18. Remove the needle roller bearing on the Lower casing unit.
19. Remove the oil seal of the oil seal casing A and remove the bearing on the forward gear.
Remove the oil seal of the water pump seat and remove the bearing on the forward gear. (CD/CT)

Propeller Shaft and Clutch Block

1. Check the claw clutch; If broken or damaged, replace it.
2. Check the propeller shaft; If worn or bent, replace it.

Install the Claw Clutch

1. Install the clutch spring into the bore at the rear of the propeller shaft.
2. Install the claw clutch. Position the "F" or "●" towards the forward gear. Fit the clutch pin.



3. Fit the clutch ring and shift plunger.

Lower casing Unit Casing Cover

1. Check the bearing for rust and noise when rotating. If yes, replace it.
2. Remove the bearing and oil seal with the bearing puller.
Note:
Do not remove the bearing unless it is replaced.
3. Remove needle roller bearing with special tools.
Note:
When reinstalling the oil seal and needle roller bearing, use new ones.
4. Clean the casing cover with a soft brush and solvent.
5. Check the casing cover; If there is cracking or damage, replace it.

Install the Casing Cover Oil Seal and Bearing

1. Install the oil seal.
2. Fit a new bearing on the reverse gear.
Note:
Install the oil seal and bearing with special tools.
Pay attention to the installation direction and depth.
Ensure that the manufacturer's mark of the bearing faces the reverse gear.
Installation depth:

| | | |
|-----------------------|---------|--------------|
| Needle roller bearing | | 31.0~31.5 mm |
| Oil seal | Depth 1 | 13.0~13.5 mm |
| | Depth 2 | 6.0~6.5 mm |



Bearing mounting tool



Oil seal mounting tool



Needle bearing mounting tool

3. Install the reverse gear and shim.

Note:

When installing the new reverse gear and bearing, adjust the shim as required.

Drive Shaft

Check the drive shaft for bending or wear. Replace it if necessary.

Shift Cam

Check the shift cam for wear or deformation. Replace it if necessary.

Gear

Check the forward gear, reverse gear and pinion for wear or damage. Replace it if necessary.

Forward Gear Bearing

Check whether the bearing for rust and noise when rotating. Replace it if necessary.

Note:

Do not remove the bearing unless it is replaced.

When installing a new bearing, adjust the shim as required.

Check the Lower casing Unit Casing

Check whether the Lower casing device casing is cracked or damaged, and check whether the cooling water inlet is blocked. Replace it if necessary.

Check the Water Pipe

Request params was error Replace it if necessary.

Assemble the Lower casing Device Casing

1. Install the needle roller bearing with special tools.



Needle roller bearing mounting tool kit

2. Install new forward gear bearing. (If replace it)



Forward gear bearing casing mounting kit

3. Install the drive shaft seat oil seal.



Drive shaft seat oil seal installation tool kit

4. Install the shift cam, gasket and oil pump casing A, and install forward gear, drive shaft, shim and pinion.

Install the shift cam, gasket and water pump seat, and install forward gear, drive shaft, shim and pinion.

Attention:

When installing a new drive shaft, adjust the shim as required.

5. Tighten the pinion nut.
Specified torque: 95 Nm
6. Install the propeller shaft assembly.

7. Install the Lower casing unit casing cover



Lower casing unit casing cover assembly mounting tool

8. Check whether the shift gear is working properly.
9. Install the water pump assembly.
10. Install the anode and water inlet.
11. Install the propeller and slotted hexagon nut, and place a piece of wood between the anti-swirl plate and the propeller to prevent the propeller from rotating freely. Tighten the nut to the specified torque, insert the cotter pin and bend the foot of the cotter pin. Specified torque: 35 Nm

Note:


If the groove on the nut is not aligned with the cotter pin hole on the propeller shaft, tighten the nut further until it is aligned.

Install the Lower casing Unit

1. Install the locating pin.
2. Place the shift cam in the forward position. Install the Lower casing unit to the casing of the Lower casing unit and tighten the bolts to the specified value. Specified torque: 37 Nm
3. Perform the shift operation and check whether it is operating properly.
4. Inject gear oil into the oil drain screw hole with the pressure filling device.

Selection of Shims


When replacing the internal parts of the Lower casing unit or assembling a new Lower casing unit, adjust the shims as required.



Deviation Value Mark

The installation surface of the anode/heading adjusting piece of the Lower casing unit is engraved with deviation value marks, namely F, R and P respectively; Represents the difference between the actual size and the theoretical size on the casing of the Lower casing unit.

For example, the mark P is followed by +3, representing actual size which is 0.03 mm more than the theoretical
If there is no number after that deviation value, the value is considered to be 0.




the
size;
of P

Pinion Shim

1. Check the P value engraved on the Lower casing unit.
2. Attach the drive shaft to the special tool. Fit the pinion and lock the pinion nut according to the specified torque.
Specified torque: 95 Nm

3. Measure the clearance between the special tool and the pinion with a gauge,
Calculate the thickness T3 according to the formula.
Formula: $T3=M3-(P/100)$
Formula for CD/CT: $T3=M3-(P/100)+0.1$



1. 专用工具

4. Shims that can be selected.

0.10, 0.12, 0.15, 0.18, 0.3, 0.4, 0.5 mm

Note:

The thickness of the shim can be 0 ~ 0.05 thicker than T3, and the closest size is selected.

Shims for Forward Gear

1. Check the F value engraved on the Lower casing unit.
2. Turn the outer ring of the forward gear bearing so that the roller falls completely into the bearing casing.


3. Measure the bearing height and calculate the thickness T1 according to the formula.

Formula: $T1=26.70+(F/100)-M1$

Formula for CD/CT: $T1=24.2+(F/100)-M1$

Note:

When measuring the thickness, it is measured at 3 points.
Average the results.



4. Shims that can be selected.

0.10, 0.12, 0.15, 0.18, 0.3, 0.4, 0.5 mm

Note:

The thickness of the shim can be 0 ~ 0.05 thinner than T1, and the closest size is selected.

Shims for Reverse Gear

1. Check the R value engraved on the Lower casing unit.
2. Formula: $T2=0.5+(R/100)$
Formula for CD/CT: $T2=0.5-(R/100)$

3. Shims that can be selected.

0.10, 0.12, 0.15, 0.18, 0.3, 0.4, 0.5 mm

Note:

The thickness of the shim can be 0 ~ 0.05 thinner than T2, and the closest size is selected.
For CD/CT, the thickness of the shim can be 0 ~ 0.05 thicker than T2, and the closest size is selected.

Common Faults and Solutions

| Fault Type | Cause | Solution |
|-------------------------------|--|---|
| The engine cannot start | No fuel in the fuel tank | Fill up the fuel tank with clean fresh fuel |
| | Fuel is contaminated or obsolete | |
| | Fuel filter is blocked | Replace the fuel filter |
| | Fuel pump failure | Repair or replace the fuel pump |
| | Fuel tank cap vent screw not loosened | Loosen the vent screw |
| | Spark plug is contaminated or the type is incorrect | Check the spark plug. Clean the spark plug or replace with the correct type of spark plug |
| | Incorrect installation of the spark plug cap | Check and reinstall the spark plug cap |
| | Ignition wire failure | Check the wiring. Tighten the loose wire and replace aged or broken wire. |
| | Ignition parts Failure | Replace |
| | The engine stop safety cable is not connected to the emergency stop switch assembly. | Connect the cable to the switch |
| Engine internal parts failure | Repair | |
| Abnormal engine idle or stall | Spark plug is contaminated or the type is incorrect | Clean the spark plug or replace with the correct type of spark plug |
| | Fuel system is clogged | Check the fuel pipe for extrusion, winding or blockage |
| | Fuel is contaminated or obsolete | Fill up the fuel tank with clean fresh fuel |
| | Fuel filter is blocked | Replace the fuel filter |
| | Incorrect spark plug clearance | Adjust the clearance to the specified value |
| | Ignition wire failure | Check the wiring. Tighten the loose wire and replace aged or broken wire. |
| | Incorrect oil grade | Change to the oil of the specified grade |
| | Thermostat failure | Replace |
| | Fuel pump failure | Replace |
| | The vent screw for the fuel tank cap is not loosened | Loosen the vent screw |
| | Fuel joint is not connected correctly | Connect it correctly |
| | Chock valve handle is pulled out | Return it to its original position |
| Outboard angle too high | Return it to its normal operating position | |
| Engine weakness | Propeller is broken | Repair or replace the propeller |
| | Incorrect trim angle | Adjust the trim angle to an appropriate angle |
| | Incorrect installation height of outboard motor | Adjust it to the correct height |
| | The bottom of the ship is polluted by Lower casing organisms. | Clean the bottom of the ship |
| | The gearbox is twined by aquatic plants or foreign matters | Remove foreign matter and clean it |

Continued table (I)

| Fault type | Cause | Solution |
|---------------------------------------|--|---|
| Engine weakness | Spark plug is contaminated or the type is incorrect | Clean the spark plug or replace with the correct type of spark plug |
| | Fuel system is clogged | Check the fuel pipe for extrusion, winding or blockage |
| | Fuel filter is blocked | Replace the fuel filter |
| | Fuel is contaminated or obsolete | Fill up the fuel tank with clean fresh fuel |
| | Incorrect spark plug clearance | Adjust the clearance to the specified value |
| | Ignition wire failure | Check the wiring. Tighten the loose wire and replace aged or broken wire. |
| | Ignition parts failure | Replace |
| | The engine oil grade is incorrect or too much oil is added. | Change to the oil of the specified grade or add it to the appropriate position of the oil dipstick. |
| | Thermostat failure | Replace |
| | Fuel pump failure | Replace |
| | Fuel joint is not connected correctly | Connect it correctly |
| Incorrect spark plug specification | Replace it with the correct model | |
| Excessive vibration of outboard motor | Propeller is broken | Repair or replace the propeller |
| | Propeller shaft is broken | Replace |
| | The propeller is twined by aquatic plants or foreign matters | Remove foreign matter and clean it |
| | Mounting bolt of outboard motor is loose | Tighten the bolt |
| | Steering shaft is loose | Tightening the spindle |
| | Steering shaft is broken | Replace |